


Christmas Tree Installtion Instruction



- Note.
- 1. Be careful not to pinch any of the light wires (if applicable) between the hinge when shaping the branches.
 - 2. Make sure all bolts are tightly screwed in to keep the tree stable
 - 3. When not in use, store neatly in a cool, dry location protected from sunlight.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.