





















# Kids Bookshelf & Toy Storage Organizer





# List of Assembly Parts

<b>Cam Lock</b>  A X2 pcs	<b>Cam Bolt</b>  B X2 pcs	<b>Wood Dowel</b>  C X34 pcs	<b>Dowel Nut</b>  D X24 pcs	<b>Connector Bolt</b>  E X24 pcs	<b>Tube Screw</b>  F X12 pcs	<b>Hinge Screw</b>  G X12 pcs	<b>Hinge</b>  H X2 pcs
<b>Door Handle</b>  I X1 pc	<b>Door Handle Screw</b>  J X1 pc	<b>Door Stopper</b>  K X1 pc	<b>Door Stopper Screw</b>  L X2 pcs	<b>Wall Bracket</b>  M X1 pc	<b>Bracket Screw</b>  N X1 pc	<b>Wall Anchor</b>  O X1 pc	<b>Wall Anchor Screw</b>  P X1 pc
<b>Allen Key</b>  Q X1 pc							




**Note to Customer:** In the event that you have any questions or issues with the assembly of this product, please don't hesitate to contact us and we will be more than happy to assist with your questions and provide you with the best possible outcome.


STEP 1



2pcs





2pcs




2pcs


STEP 2



3pcs





3pcs




3pcs

STEP 3




6pcs





STEP 4






STEP 5




STEP 6





STEP 7



## STEP 8




## STEP 9



4pcs





4pcs







2pcs

## STEP 10






## STEP 11

Arrow on Part A  
Points Towards  
Entry Hole to Enable  
Part B to be Inserted





STEP 12

Turn Clockwise to  
Lock into Place










# STEP 13




Adjust Door Position:




## STEP 14

### IMPORTANT

The door hinges must be positioned correctly to prevent the risk of pinching or jamming of children's fingers in the gap to the left of the opened door. By turning the front screw anti-clockwise (to the left) as illustrated below, the gap to the left of the open door will be less than 5mm which is in optimum safety position.



## STEP 15



## STEP 16

