


Thank you for your purchase!



Aluminum Bar Height Table

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Have a Question/Concern?

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

Our Warranty Statement

This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.

- Non-moving metal parts are warranted for 5 years.
- Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- All other items are warranted for 1 year.

Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less.

Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.

This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

PARTS

A	Table Top	1PC	B	Cross Base	1PC	C	Column Poles	2PCS
D	Column Sleeves	2PCS	E	Column Sleeve Connector	1PC	F	Nut	4PCS
G	Washer	2PCS	H	Wrench	1PC	I	Floor Glides	4PCS
J	Base Weight	1PC	K	Table Top Mechanism	1PC	L	Lock Washer	2PCS

STEP 1

STEP 1A: Turn table top (Part A) upside down on a clean surface. Remove Bolt from Table Top Mechanism. Attach Table Top Mechanism (Part K) onto Table Top (Part A) using the removed bolt.

STEP 1B: Close the Table Top Mechanism. Place the Washer (Part G), the Lock Washer (Part L) and the Nut (Part F) onto the Table Top Mechanism. Insert threaded end of Upper Column Pole (Part C) through parts F,L&G and into the Table Top Mechanism. Use the included Wrench (Part H) to tighten the Nut.

STEP 1D: Slide the first Base Sleeve (Part D) over the Column Poles. Slide the Base Sleeve Connector (Part E) over the Column Poles and insert into the first Base Sleeve (Part D). Slide the second Base Sleeve (Part D) over the Column Poles and press securely onto the Base Sleeve Connector (Part E).

STEP 2

STEP 2A: Place table on its top and place the Cross Base (Part B) upside down over the threaded Column Pole (Part C).

STEP 2B: Place base weight (Part J) onto threaded Column Pole (Part C). **Note: Use Caution, Base Weight Is Heavy.** Place Washer (Part G), Lock Washer (Part L) and 2 Nuts (Part F) onto threaded Column Pole. Securely tighten Nuts and return table to the upright position.

Caution: Base Weight (Part J) Is Very Heavy

Thank you for your purchase!