


ASSEMBLY INSTRUCTIONS



Important Notice:









Pls check all parts are included before assembly.

Questions and After-Sales Service:

For any queries, or if something's damaged, please feel free to contact our official support via purchase platform for prompt and warm assistance.


Thanks for your cooperation. Take care and stay safe~

Parts List

Ax2 		Bx8 	
Cx2 		Dx2 	
Ex2 		Fx16+2  M6X10mm	
Gx8+2  M6X16mm	Hx8+2  M6X30mm	Ix2  M6	


Installation Steps

1




Attach the Pallet (D) to the Seat (A) with screws (G) by using the allen wrench (I). Don't screw 100% until all of them are right in the holes so that you can adjust slightly during the process of assembly.


2



Attach the Metal Legs (B) to the connector (C) with the screw (F) by using allen wrench (I) . Don't screw 100% until all of them are right in the holes so that you can adjust slightly during the process of assembly.



3




Notice ! ! !

The side of the footrest with small holes should face the ground during installation.


Attach the Footrest (E) to the Metal Legs with screws (H) by using allen wrench (I) .Don't screw 100% until all of them are right in the holes so that you can adjust slightly during the process of assembly.

4




Tighten all screws fully.

5



Now turn the assembled legs upright and locate the center hole of the Connector (C). Push down firmly until the connection is secure.

6



Assembly completed. If you find the chair not level, please adjust by rotating the feet pads on the legs.

Notice ! ! !

The chair will be a slight shake when using. This is not a quality defect, which is the characteristic of this product itself. If it is not artificially violent shaking, no more than 2 degrees of shaking is safe.

