

SUPER MAGNETIC MESH CURTAIN

YOUR HANDS FREE SCREEN DOOR

CARE AND INSTALLATION INSTRUCTIONS

I. GETTING STARTED:

1. Ensure the Super Magnetic Mesh hands free screen door is clean- dust and debris free.
2. Determine the proper direction for installation:
 - If your door opens in, install item on the outside of door frame.
 - If your door opens out, install item on the inside of the door frame.
 - For sliding doors, install item to the outside of the door frame and the stationary door.
3. Determine and mark the center of the top door frame.

II. HANGING INSTRUCTIONS:

1. Lay Super Magnetic Mesh screen flat on the floor.
2. Align magnets in the center.

Note: It is normal for the top panel to have a larger gap between magnets and trim than the bottom panel.
3. Check and ensure the magnets are functioning correctly. (The magnets should attract each other symmetrically.)
4. Peel the adhesive backing off of the hook and loop strips.

Note: If available, a long hook and loop strip may be used in place of smaller hook and loop strips.
5. Apply the hook and loop strips as shown in the diagram.
6. Peel off the adhesive covering from the hook and loop strips attached to the top of the curtain and apply to the door frame starting from the center and working you way to the edges.

Note: Hang the screen high enough to ensure it does not touch or drag on the floor.
7. Ensure magnets are properly aligned.
8. Peel and attach remaining hook and loop strips on the side without magnets to the door frame.

III. ADDITIONAL INFORMATION REGARDING HANGING INSTRUCTIONS:


1. For wooden frames, wood tacks (provided) can also be used.
2. For plastic frames use ONLY the hook and loop strips. Do NOT use wood tacks on plastic frames.
3. Wood tacks make and leave holes.
4. If magnets do not snap together, adjust positioning of mesh until magnets snap shut together. Special attention may be needed in adjusting the width positioning of the mesh to ensure proper function of mesh.

IV. CARE INSTRUCTIONS:

1. Do NOT use abrasive cleaning materials on this product.
2. Gently wipe off mesh with a soft, damp, lukewarm cloth.
3. Allow mesh to air-dry.
4. Do NOT dry clean.
5. Do NOT put in dryer.

V. SAFETY INFORMATION:

1. Maintain adequate distance from stove tops, oven, and all other heat sources.
2. Take extra caution if and when using wood tacks. Always keep away from minors.
3. Keep minors away from packaging material and storage bag.
4. The Super Magnetic Mesh screen may not function properly if not installed correctly.
5. Product may cause electromagnetic interference.
6. People who use medical devices should consult their doctor before using.



WARNING:

- Super Magnetic Mesh screen is NOT a barrier.
- Super Magnetic Mesh screen will NOT keep minors, small children, or pets from getting out.