


# Cabinet



We strive to provide fine furniture products, built with quality materials and hand finished details. Please carefully follow the assembly instructions to ensure your furniture is assembled correctly to provide long lasting enjoyment.

# Care and Maintenance Instructions

## Keeping Your Furniture Beautiful

Quality furniture is a significant investment expected to last for generations. To maintain its beauty and help it last, furniture needs the right care. No finish is totally indestructible. But with regular care, the finish will last much longer, providing years of enjoyment to you.

## Tips to Protect and Care for Your Furniture

1. Avoid placing your furniture in direct sunlight, as sunlight causes fading.
2. Avoid extreme changes in temperature by arranging furniture away from radiators, heat and air vents and air conditioning units.
3. Avoid placing plastic or rubber materials (lamp bases, notebooks, placemats, etc.) on your furniture, as certain plastics contain ingredients that may damage the finish.
4. Periodically rotate accessories on furniture so they do not sit in the same spot all the time.
5. Use pads, cloth or felt to protect the furniture surface from plastic, rubber, hot dishes, beverages, bookends, flowerpots and vases.
6. Clean up spills immediately. Use a blotting rather than a wiping action. Water left over a long period of time will cause white spots in the finish. Alcohol, perfume, after-shave and medications can cause severe finish damage.
7. Use a protective pad when writing on the furniture surface.
8. Lift and place objects rather than dragging them across the furniture surface.
9. Avoid placing furniture directly under windows.

**Wood Furniture Care:** We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Clean the surface by rubbing in the direction of the grain. We recommend polishing your furniture approximately every six months, using a clean, soft, lint-free cloth and rubbing the polish in the direction of the grain. Guardsman furniture polish or any furniture polish that doesn't contain silicone is recommended.

**Leather Furniture Care:** Wipe spills immediately with clean cloth or sponge. For spots or stains and daily cleaning, clean with mild non-detergent soap. Rinse well, gently wipe off, and allow to air dry. Cleaning Butter, Oil or Grease from Leather: Wipe leather with a clean cloth, and leave alone. The oil will be absorbed by the leather. DO NOT APPLY WATER. Also, do not use saddle soap, cleaning solvents, furniture polish, oils, varnish, abrasive cleaners, ammonia or any other type of chemical solution.

**Granite Furniture Care:** Our granite is not sealed, so you may want to apply an over-the-counter sealant, which will provide a small amount of surface protection, but we still recommend cleaning spills promptly. Use a slightly damp cloth to clean as needed. Wipe dry. We also do not recommend using abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach, and furniture polish. Be sure to use trivets, coasters, placemats, and adhesive felt pads to help prevent scratches.

**Wicker Furniture Care:** Regular cleaning is recommended for wicker, as it generally cannot endure harsh or abrasive treatments. This also minimizes mildew buildup. To remove dirt and debris, vacuum with a dust-brush attachment or use a dry paintbrush. Clean with a mild soap solution. Scrub, and rinse. Avoid using too much water, which can weaken the fibers. Avoid sitting on the wicker when still damp, which can cause wicker to sag.

**Metal Furniture Care:** Because most metals, except aluminum, are subject to rust, metal furniture is usually finished with layers of clear varnish, paint, or a durable powder coating. Use a mild soap solution, and scrub, rinse, and dry. After cleaning, apply a coat of quality liquid or paste auto wax with a lint-free cloth if recommended by the furniture's manufacturer. Use a silicone spray to lubricate swivels and glides on chairs.















**Butcher Block Care:** For best results, clean finished butcher block surfaces with soapy water or commonly available kitchen counter top cleaners. Do not use abrasives or powder cleansers. Do not allow moisture stand on the surface for prolonged periods of time. To sanitize, rinse the butcher block with white vinegar by using a vinegar-water solution in a spray bottle, spritz the butcher block all over. Let sit for a while. While that sits, make a lemon salt mixture by pouring about 1/4 cup salt into a bowl, and stir in enough lemon juice to make a paste, adjust the consistency as you go, to make a workable paste. The final step, using a scrub brush, thoroughly scrub your butcher block with the lemon-salt paste. If the paste gets too dry, sprinkle on a little more lemon juice. Rinse well, and squeegee off as much water as you can, and then let it dry overnight. Make sure to seal it before you get it dirty.

again. Pour out a small amount of oil, and rub it into the wood using a cloth or paper towel. As the oil soaks in, add more and continue rubbing and polishing with the grain until the oil is absorbed. The first time you seal your butcher block, it may take several applications before it stops "drinking" oil, but in later cleanings you'll just need to refresh it. Keep adding oil until no more soaks in, remove any excess with a cloth.



















**Outdoor Cushion Care:** Please note our cushions are made from a polyester foam, and the covers are made from a moisture resistant polyester blend. This does not mean they are waterproof! Cushions should be stored and covered when not in use to protect them from rain, sunlight, and other staining agents. We do not recommend leaving cushions out in inclement weather, and if cushions become wet, please dry them immediately by removing the cushion from the cover so they can dry separately. Wring out any excess moisture before drying. Air dry only!

**Outdoor Furniture Storage:** We highly recommend storing any outdoor furniture during the winter and/or rainy seasons. Before storing your furniture, please ensure all moisture collected in the frame tubes has been drained out and dried. When outdoor furniture is not in use, we recommend covering all the furniture to protect it against the elements.

# PART LIST

<b>A</b> 	<b>B</b> 	<b>C</b> 	<b>D</b> 	<b>E</b> 
Top Panel 1 PC	Left Side Panel 1 PC	Right Side Panel 1 PC	Bottom Frame 1 PC	Fixed Shelf 1 PC
<b>F</b> 	<b>G</b> 	<b>H</b> 	<b>I</b> 	<b>J</b> 
Leg 4 PCS	Top Back Panel 1 PC	Bottom Back Panel 1 PC	Door Panel 1 PC	Front of Drawer 2 PCS
<b>K</b> 	<b>L</b> 	<b>M</b> 	<b>N</b> 	
Left Side Panel of Drawer 2 PCS	Right Side Panel of Drawer 2 PCS	Back Panel of Drawer 2 PCS	Bottom Panel of Drawer 2 PCS	

# HARDWARE LIST

#1		#2		#3		#4		#5	
M6x45						D7xØ3.5x12		D7xØ4x25	
Allen Bolt		Flat Washer		Spring Washer		Screw		Screw	
8 PCS		10 PCS (Extra 2)		10 PCS (Extra 2)		16 PCS (Extra 2)		26 PCS (Extra 2)	
#6		#7		#8		#9		#10	
Ø6x30				Ø9mmx5/32"x1"		Ø7x2.5x12mm		Ø15x12mm	
Wood Dowel		Handle		Round Head Bolt		Screw		Cam Lock	
4 PCS		3 PCS		6 PCS		26 PCS (Extra 2)		10 PCS (Extra 2)	
#11		#12		#13		#14		#15	
Ø7*35mm		Ø8x30		M4				D6xØ3x12	
Cam Bolt		Wood Dowel		Allen Wrench		Safety Strap Kit		Screw	
10 PCS (Extra 2)		10 PCS (Extra 2)		1 PC		1 PC		10 PCS (Extra 2)	
#16		#17		#18					
Door Insert		Spring Hinge		Door Catch					
2 PCS		2 PCS		2 PCS					

## ADDITIONAL TOOLS (Not Provided)


Note: It is not recommended to use power tools during assembly.




Phillips Head Screwdriver

Step 1. Insert cam bolts (part #11) into pre-drilled holes of top panel (part A) by using phillips head screwdriver. Attach door catch (part #18) to left side panel (part B) and right side panel (part C) by using screws (part #15) and phillips head screwdriver. Attach door insert (part #16) to door panel (part I) by using screws (part #15) and phillips head screwdriver.

NOTE: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.




Step 2. Attach handles (part #7) to door panel (part I) and front of drawer (part J) by using round head bolts (part #8) and phillips head screwdriver.






Step 3. Attach left side panel of drawer (part K) and right side panel of drawer (part L) to front of drawer (part J) by using screws (part #5) and phillips head screwdriver. Slide bottom panel of drawer (part N) into the grooves of left side panel of drawer (part K) and right side panel of drawer (part L). Attach back panel of drawer (part M) to left side panel of drawer (part K) and right side panel of drawer (part L) by using screws (part #5) and phillips head screwdriver.





Step 4. Attach legs (part F) to bottom frame (part D) by using allen bolts (part #1), flat washers (part #2), spring washers (part #3) and allen wrench (part #13).



Step 5. Insert wood dowels (part #12) and cam bolts (part #11) into bottom frame (part D) by using phillips head screwdriver as shown.


NOTE: Do not overtighten cam bolts. Stop tightening once threads on cam bolt are no longer visible.



#11  x4

#12  x4


Step 6. Attach fixed shelf (part E) to left side panel (part B) by using wood dowels (part #6), screws (part #5) and phillips head screwdriver as shown.





#5  x4



#6  x2

Step 7. Attach fixed shelf (part E) to right side panel (part C) by using wood dowels (part #6), screws (part #5) and phillips head screwdriver as shown.



#5  x4  
#6  x2



Step 8. Attach left side panel (part B) and right side panel (part C) to bottom frame (part D) by using wood dowels, cam locks (part #10) and phillips head screwdriver.  
NOTE: Cam locks must rotate full 180°. See pictured insert.





#10  x 4


Step 9. Attach top panel (part A) to left side panel (part B) and right side panel (part C) by using cam locks (part #10), wood dowels (part #12) and phillips head screwdriver.

NOTE: Cam locks must rotate full 180°. See pictured insert.




#10  x 4  
#12  x 4

Step 10. Attach top back panel (part G) and bottom back panel (part H) into place by using screws (part #9) and phillips head screwdriver.




#9  x 24




Step 11. Attach door panel (part I) to fixed shelf (part E) by using hinges (pre-assembled), screws (part #4) and phillips head screwdriver.









Step 12. Attach spring hinge (part #17) to left side panel (part B) and right side panel (part C) by using screws (part #4) and phillips head screwdriver.



Step 13. Slide completed drawers into place.




	<b>A</b> 	<b>B</b> 	<b>C</b> 	<b>D</b> 	<b>E</b> 
<b>Safety Strap Kit</b> 1 PC	<b>Wall Anchor</b> A x1 PC	<b>Washer</b> B x 2 PCS	<b>D8*3/4" Short Screw</b> C x 1 PC	<b>D8*1-1/2" Long Screw</b> D x 1 PC	<b>Safety Wall Strap</b> E x 1 PC

## SAFETY STRAP WALL ASSEMBLY INSTRUCTION

1) Insert short screw (part #C) through washer (part #B) and safety wall strap (part #E) and screw it into the top center of top back panel (part G).

2) Drill a 11/32" hole where you want to secure your unit. The hole should be at the same height as the hole in the top center of top back panel (part G). Tap wall anchor (part #A) into the hole.

3) Insert long screw (part #D) through a washer (part #B) and wall safety strap (part #E) into wall anchor the top center of top back panel (part G).



## Limited Manufactures Warranty