
Installation Manual


MOTIVATE
YOUR LIFE !





Thank you for shopping with us!


We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.

Hardware


NO.	Draw	QTY
A	 Screws Ø4x14mm	44
B	 Two-in-one connector	21
C	 Two-in-one connector	21
D	 Wood plug	6
E	 Plastic anchor(Ø10mm)	4

NO.	Draw	QTY
F	 Screws for fix on the wall	4
G	 Bracket (53x70x44mm)	2
H	 Bracket (19x19x35mm)	2
I	 Hinges (Full cover)	4
J	 Anti-collision gasket	4
K	 Screwdriver	1


Recommended tools




Dimensions




Components





Step 1






	x3
B	
	x3
C	
	x1
K	







Notes: Screw installation depth as shown

Attention:The lock handle arrow points to the side face.




Step 2






Note:The D parts are used for these two holes


	x3
B	
	x3
C	
	x2
D	
	x1
K	




first step




second step



third step




Step 3




x4	B
x4	C
x1	K

Step 4




x2	B
x2	C
x1	D
x1	K

Step 5




x9
B
x9
C
x3
D
x1
K

Step 6




x2
G
(∅4 x 14mm)
x12
A
Tool

Step 7




x2
H
(∅4 x 14mm)
x8
A
Tool

Step 8




x4
I
(∅4 x 14mm)
x24
A
x4
J
Tool


You can adjust the doors by tightening or loosening the screws on the hinge.




Step 9




Step 10




Step 11




Step 12




Step 13




Finished



Dimensions



Back View



Front View

CARE CLEANING AND MAINTENANCE

1.Dust regularly with a soft , dry cloth.

2.Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.

3.Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.

4.The sink top is resilient, but care needs to be taken to preserve its appearance.

5.Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.