

OFFICE CHAIR

5261















SAFETY INSTRUCTIONS

- Keep children and pets away while assembling the product.
- Do not let children climb on or play with the product.
- Always use the product on a firm, level ground.
- Do not use this product if any parts are missing, damaged, or worn. And contact us immediately , pls.
- Do not stand on the seat.
- Do not sit on the armrest.
- Use this product for seating one person at a time.
- Do not use the chair unless all bolts and screws are firmly secured.
- Avoid contact with sharp objects to prevent puncturing the fabric.

ASSEMBLY INSTRUCTION

Parts List

A  5 pcs	B  5 pcs	C  1 pcs	D  1 pcs	E  1 pcs	F  1 pcs
G  1 pcs	H  2 pcs	I  1 pcs	J  1 pcs		
①  M6*15mm 10 pcs	②  M6*30m 4 pcs	③  M8*25mm 3 pcs	④  M8*40mm 4 pcs	⑤  4 pcs	⑥  1 pcs

Please read this manual carefully before operating and keep it properly.

Any parts missing, please send your order number and missing parts to: **Sj2-Service@outlook.com**

ASSEMBLY INSTRUCTION

Chair Assembly

Step 1


A*5

B*5

C*1

①*10

⑥*1



ASSEMBLY INSTRUCTION

☐ Return ☐ Exchange

Account Number

Order Number

Item Number

Phone

Mailbox

Reason

Remarks:

Notice

1. Thank you for purchasing the product.
2. Please apply on the Amazon and then return the goods.
3. Please send the photo of this card to us by email before return
4. Mail to : **Sj2-Service@outlook.com**

ASSEMBLY INSTRUCTION

Chair Assembly

Step 7




ASSEMBLY INSTRUCTION

Chair Assembly

Step 2


D*1



Step 3

②*4

G*1




ASSEMBLY INSTRUCTION

Chair Assembly


Step 4

- ③*3
- F*1
- E*1



Step 5


- H*2
- ④*4
- ⑤*4




ASSEMBLY INSTRUCTION


Chair Assembly

Step 6





OPERATION DECLARATION



按键功能介绍:

1.  **BUTTON**: TAP THE ON / OFF DEVICE;
2.  **BUTTON**: MESSAGE MODE SELECTION CAN BE SWITCHED TO CHOOSE 8 MESSAGE MODES;
3.  **BUTTON**: POWER ON, PRESS ON THE HEATING FUNCTION, AND PRESS OFF THE HEATING FUNCTION AGAIN;

4. BUTTON: MESSAGE INTENSITY

ADJUSTMENT—GRADUALLY ENHANCED (3 GEAR

ADJUSTMENT LOW, MEDIUM AND HIGH);

5. BUTTON: MESSAGE INTENSITY

ADJUSTMENT—GRADUALLY WEAKENED (3 GEAR

ADJUSTMENT HIGH, MEDIUM AND LOW

6. BUTTON: MESSAGE SITE SWITCHING SELECTION (3

SITES SWITCHING),

NOTES:

1. Message red Indicator light 1–8, select the message mode to display the corresponding Indicator light on;

2. Green Indicator light for the message area, Choose the message site The corresponding Indicator light is flashing;

3. Strength red Indicator light 1–3, When adjusting the message intensity, the red Indicator light displays the corresponding intensity light, When the message intensity adjustment is stopped, After 5 seconds, The Indicator light will display the message mode Indicator light status;

4. Open the heating, The red Indicator light is on, Because the heating belongs to an independent function, When the hand control open key is closed, The heating function is not affected, Need to self, open / close;

5. Heating requires a waiting time of 3 minutes.