


ASSEMBLY INSTRUCTIONS



+ Do Not Use Power Tools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

- Do not** assemble the product if the parts arrived damaged.
- Do not** assemble if Hardware parts are missing.



2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, please make sure to tighten all the bolts periodically, or use a thread locker adhesive.


+ Parts Included

① Chair back (1 pc)

② Seat frame (1 pc)





③ Front legs (2 pcs)



+ Parts Included


A. Bolt
Ø8x80mm (4 pcs)

B. Bolt
Ø8x40mm (2 pcs)




C. Bolt
Ø8x60mm (4 pcs)

D. Spring Washer
Ø8xØ12mm (10 pcs)



E. Flat Washer
Ø8xØ19mm (10 pcs)

F. Allen Key (1 pc)



ASSEMBLY INSTRUCTIONS

