

ASSEMBLY INSTRUCTION
















ITEM : N759P427900 / N759P427901

Storage Cabinet











A
F
F
C
E
B2
D
E
D
B1
K
K
G
H2
N2
Q
P
Q
O
Q
O
M
N1
J
J
I
H1
T
S
T
S
S
R
S
R
U
U
L


















PART LIST (Box 1 - N759P427900/Hardware in this SKU)

(A) x 1 Top Panel 	(H1) x 1 Bottom Left Side Panel 
(D) x 2 Left adjustable shelf 	(H2) x 1 Bottom Right Side Panel 
(E) x 2 Right adjustable shelf 	(L) x 1 Bottom Frame 
(Q) x 3 Bar of Door Shelf 	(I) x 1 Bottom vertical divider 
(O) x 2 Bottom Shelf of Door Shelf 	(J) x 2 Bottom Back Bar 
(P) x 1 Upper Shelf of Door Shelf 	(S) x 4 Side Panel 
(G) x 1 Middle Panel 	(T) x 2 Back Panel 
(R) x 2 Tilt-out door panel 	


PART LIST (Box 2 - N759P427901)

B1 x 1 Upper Left Side Panel 	K x 2 Upper Back Panel 
B2 x 1 Upper Right Side Panel 	N1 x 1 Left Side Panel of Door Shelf 
C x 1 Upper vertical divider 	N2 x 1 Right Side Panel of Door Shelf 
M x 1 Upper Left Door 	U x 2 Bottom Panel 
F x 2 Upper Back Panel 	

PACKAGE CONTENTS


1	2	3	4
 4PCS	 Ø3x12mm 17PCS	 4PCS	 Ø3x15mm 9PCS
5	6	7	8
 4PCS	 Ø3x10mm 9PCS	 3PCS	 M4x12 mm 7PCS
9	10	11	12
 Ø15x9mm 57PCS	 Ø6 x35 mm 57PCS	 17PCS	 Ø6 x30 mm 65PCS
13	14	15	16
 Ø3x12mm 52PCS	 Hinge 3PCS	 Ø4x15mm 19PCS	 Left 2PCS
17	18	19	
 Right 2PCS	 Ø3.5x12mm 17PCS	 2PCS	

STEP 1




3	1PC
4	2PCS
10	6PCS

STEP 2




12	12PCS

STEP 3




3	2PCS
4	4PCS
10	6PCS

STEP 4




10	8PCS
12	4PCS


STEP 5




12		12PCS


STEP 6



10		2PCS
12		4PCS


STEP 7






9	2PCS


STEP 8






9	8PCS


STEP 9






9		6PCS


STEP 10






9		6PCS


STEP 11





3	1PC
4	2PCS
10	6PCS


STEP 12













9	6PCS


STEP 13




13	51PCS

STEP 14



1	4PCS
2	8PCS
5	2PCS
6	4PCS
10 	8PCS


STEP 15



X4

12 	16PCS


STEP 16



X2


10 	8PCS

STEP 17




9		8PCS

STEP 18




STEP 19




9	8PCS

STEP 20




16	2PCS
17	2PCS
18	8PCS

STEP 21




2		8PCS

STEP 22




18		8PCS

STEP 23




7		2PCS
8		4PCS

STEP 24




11		8PCS

STEP 25




11		8PCS

STEP 26




5		2PCS
6		4PCS
10		6PCS

STEP 27




7	1PC
8	2PCS
14	3PCS
15	6PCS


STEP 28





10	6PCS


STEP 29















9	6PCS
12	12PCS

STEP 30











9	6PCS
12	4PCS

STEP 31



15		12PCS

STEP 32






Tighten the Screw marked Ⅱ to fasten hinge. The door may need to be adjusted so that all the spaces between the door and the unit sides are equal.
To adjust, follow instructions:

1. Side adjustment 4 mm
   To move the door towards the side panel, loosen screw Ⅰ and tighten screw Ⅱ .
   To move the door away from the side panel, loosen screw Ⅱ and tighten screw Ⅰ .
2. Depth adjustment 4 mm
   Loosen screw Ⅱ (just one turn), adjust door to desired position, re-tighten screw .
3. Height adjustment
   Loosen screw ② , adjust door to desired position, re-tighten screw .

WARNING

Serious or fatal crushing injuries can occur from furniture tip-over.
If the furniture tip over restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.

A1		4	D1		2
B1	 M4 X 20mm	2			
C1	 M4 X 40mm	2	E1		2



NOTE: The screwdriver is not included in the hardware pack.

