

Keep these instructions for future reference

Place furniture away from a heat source, an air-conditioning unit, very hot surroundings and direct sunlight.

If there is a need to move the furniture, please remove all loose items and have extra hands to help lift the furniture to the desired location. Dragging the furniture will damage both the furniture and the floor.

A wooden stop block is attached to the inside back of each drawer and will block the drawer from easily falling forward and out. The stop block can be turned to allow the drawer to be fully removed when necessary. Please regularly check the stop block is in its vertical position to prevent the drawer from falling out during normal use.

General Care for Longer Lasting Furniture

Always use coasters/placements underneath hot objects, such as pans, plates or glassware to protect the surface of the furniture.

If any liquid is spilled on the wood surface, wipe immediately but gently, using a clean, firmly wrung damp cloth. Dry afterwards using another clean, dry cloth.

For regular cleaning, use a damp cloth or sponge with clean water. Wipe across the whole surface as one.

Do not use spirits, bleaches or any other chemical cleaners to clean furniture.