


**ASSEMBLY INSTRUCTIONS / INSTRUCTIONS
D'ASSEMBLAGE / INSTRUCTIVO DE ARMADO**



FG-KG-PU-19-640-WYUK

NOTES ON ASSEMBLY / NOTES POUR L'ASSEMBLAGE / NOTAS SOBRE EL ENSAMBLE

- To ensure ease of assembly read all instructions before assembly and follow step by step illustrations.
- Keep instructions for future use.
- Adult assembly required.  2 person required. 
- Due to the presence of small parts during assembly, keep out of reach of children until assembly is complete.

- Pour assurer l'assemblage facile veuillez lire toutes les instructions avant l'assemblage et veuillez suivre les illustrations pour chaque etapes.
- Veuillez garder ces instructions pour l'usage ulterieur.
- Assemblage requis pas un adulte.  2 personnes requises. 
- Due a la presence de petite pieces durant l'assemblage, veuillez garder hors de porter des enfants jusqu'a ce que l'assemblage soit completer.

- Para garantizar la facilidad de ensamble lea las instrucciones antes de iniciar y siga paso a paso las ilustraciones.
- Guarde las instrucciones para futuras referencias.
- El ensamble requiere de un adulto.  2 personas requeridas. 
- Debido a que hay piezas pequeñas, mantenga fuera del alcance a los niños durante el ensamble, hasta que haya terminado.

MAINTENANCE TIPS / CONSEILS D'ENTRETIEN / CONSEJOS DE MANUTENIMIENTO

- Never let liquids or damp cloths sit on this furniture.
- Never use chemical cleaning products. They can damage the finish. For cleaning, use only a slightly damp cloth and wipe dry.
- To avoid dulling of the finish, do not place furniture in direct sunlight.
- Do not put plastic or rubber rings under appliances. Use cloth or felt protectors.
- To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth.

- Ne jamais laisser de liquide ou linge humide sur le meuble.
- Ne jamais utiliser de nettoyeurs à base de produits chimiques, cela va endommager le fini. Utiliser seulement un linge légèrement humide.
- Ne pas placer le meuble directement au soleil pour prévenir le ternissement.
- Évitez de déposer des appareils avec des rondelles de plastique ou de caoutchouc. Utilisez un protecteur en tissu ou en feutre.
- Pour nettoyer, utilisez un linge doux ou légèrement humecté. Essuyez par la suite avec un linge propre et sec.

- Nunca deje un líquido o un trapo húmedo sobre el mueble.
- Nunca utilice limpiadores a base de químicos, estos dañaran le acabado. Use sólo un paño húmedo.
- No exponga el mueble directamente al sol para prevenir empañamiento.
- Evite apoyar aparatos con redondeles de plástico o de goma. Utilizar un protector de tela o de fieltro.
- Para limpiar, utilice un trapo suave o ligeramente humedecido. Seque luego con un trapo limpio y seco.

WARNING **AVERTISSEMENT / ADVERTENCIA**

Please use your furniture correctly and safely. Improper use can cause safety hazards, or damage to your furniture or household items.

Serious or fatal crushing injuries can occur from furniture tip-over.

To help prevent tip-over:

- Place heaviest items in the lowest drawers.
- Do not set TVs or other heavy objects on the top of this product. Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.
- Always monitor your child's activity when in the nursery.
- Do not allow standing in drawers.
- Do not allow standing on top of this product.
- Accessory Items must be securely fastened to this product according to the instructions provided with those items.
- To avoid head injury, do not allow children to play underneath open drawers.
- Do not leave drawers open when not in use.

Use of tip-over restraints reduce, but does not eliminate, the risk of tip-over.

Prrière d'utiliser le mobilier à bon escient et avec prudence. Une mauvaise utilisation peut être à l'origine de risques d'accident ou peut endommager le mobilier et les articles ménagers.

Des blessures graves ou fatales peuvent résulter de basculement du meuble.

Afin de prévenir le basculement :

- Placer les items les plus lourds dans les tiroirs du bas.
- Ne pas placer de TV ou d'autres objets lourds sur ce produit. Ne jamais laisser un enfant grimper sur les tiroirs, les portes et les tablettes ou s'accrocher à ceux-ci.
- Ne jamais ouvrir plus d'un tiroir à la fois.
- Toujours surveiller votre activité de l'enfant lorsqu'à la pèpinière.
- Ne pas laisser debout dans des tiroirs.
- Ne pas laisser debout sur ce produit.
- Les accessoires doivent être solidement fixés sur ce produit selon les instructions fournies avec ces éléments.
- Pour éviter toute blessure à la tête, ne pas laisser les enfants jouer sous les tiroirs ouverts.
- Ne pas laisser ouvrir les tiroirs lorsqu'il n'est pas utilisé.

L'utilisation de dispositif antibasculement ne peut que réduire les risques de basculement, sans les éliminer

Por favor use el mobiliario correcta y seguramente. El mal uso puede causar riesgos de seguridad o daño a las unidades o artículos domésticos.

El vuelco del mueble puede ser causa de lesiones graves o de un aplastamiento fatal.


Para evitar la volcadura:

- Ponga las cosas pesadas en los cajones más bajos.
- No ponga televisores u otros objetos pesados encima de este producto. Nunca permita que un niño se trepe o se cuelgue en cajones, puertas o estantes.
- Nunca abra más de un cajón a la vez.
- Siempre supervisa la actividad de su hijo cuando en el vivero.
- No dejar reposar en los cajones.
- No permiten de pie en la parte superior de este producto.
- Los elementos accesorios deben sujetarse firmemente a este producto de acuerdo a las instrucciones provistas con esos elementos.
- Para evitar lesiones en la cabeza, no permita que los niños jueguen debajo abrir cajones.
- No deje los cajones abiertos cuando no está en uso.


El uso de sujetadores para evitar el vuelco sólo puede disminuir el riesgo de un vuelco, pero no lo elimina.


MINIFIX CAM & MINIFIX BOLT
CAMÉRA MINIFIX & BOULON MINIFIX
CÁMARA MINIFIX & PERNO MINIFIX

MINIFIX BOLT
BOULON MINIFIX
PERNO MINIFIX








MINIFIX CAM
CAMÉRA MINIFIX
CÁMARA MINIFIX






HARDWARE


QUINCAILLERIE / HERRAJE




(A) Minifix Bolt EU 24  46 units	(B) Minifix Cam 15/12  46 units	(C) Dowel M8 x 30mm  52 units
(D) Dowel M8 x 50mm  4 units	(E) Screw M6.3 x 50mm  4 units	(F) Screw M4 x 38mm  12 units
(G) PVC L Bracket (2 Holes)  2 units	(H) Screw M3.5 x 15mm  16 units	(I) Nail Pin  20 units
(J) Nail Leg  6 units	(K) Drawer Slide 300mm  3 sets	(L) Drawer Slide 300mm  3 sets
(M) Screw M6 x 8mm  12 unit	(N) Allen Key Z (M4)  1 unit	(O) PVC Block  4 units
(P) Screw M4 x 20mm  8 unit	(Q) Hinge 7/8"  4 units	(R) Screw #10 x 16mm  16 units
(S) Safety Strap + Washer  1 unit	(T) Screw M3.5 x 25mm  1 unit	

TOOLS NOT INCLUDED
OUTILS PAS INCLUS / HERRAMIENTAS NO INCLUIDAS



STEP 1



	
M x 12	K x 3



PLEASE ENSURE TO FIX THE SCREWS AS PER ABOVE POINTED HOLES
INSTRUCTION TO AVOID DISTORTION OF OVERALL LOOK OF PRODUCTS



STEP 2


A x 6






STEP 3


A x 4






STEP 4

	
D x 2	C x 3





STEP 5

	
D x 2	C x 3





STEP 6


B x 6





STEP 7

	
O x 4	P x 8





STEP 8


A x 10





STEP 9


C x 1






STEP 10

		
C x 3	G x 2	H x 4





STEP 11

	
E x 4	C x 2






STEP 12





C x 6



STEP 13





STEP 14



STEP 15





B x 7



STEP 16





A x 9





STEP 17


C x 2



STEP 18



	
C x 6	J x 6



STEP 19





B x 9






STEP 20






A x 11






STEP 21






STEP 22






STEP 23






STEP 24






STEP 25



STEP 26






STEP 27




(x3)

STEP 28



(x3)



STEP 29



(x3)

STEP 30




F x 12



(x3)

STEP 31

	
L x 3	H x 12



(x3)

STEP 32

**WARNING!**



In order to help prevent overturning, this product must be used with the wall anti-tip/ device provided.

- Furniture can tip and cause injuries to persons. Please use anti-tip strap/ device provided.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- Do not place heavy items on top of furniture unless the furniture has been designated for this purpose.





Please ignore if furniture without drawers:

Furniture with Drawer's :-

- Place heaviest items in the lowest drawers.
- Never open more than one drawer at a time.
- Do not place heavy items in the top drawer.



Please note that only anti-tip strap/ device and screw are provided, you will need to provide wall plugs and screw applicable for your wall type.

This is permanent label. Please do not remove!





STEP 33

	
Q x 4	R x 8




STEP 34



R x 8



A. Lateral adjustment (Moving Door Left-Right)
by screw adjusting





B. Vertical adjustment (Moving Door Up-Down)
via slot in the mounting plate



C. Front-to-back adjustment (Spacing Door Off
Carcas) by slacking the hinge arm mounting
screw

STEP 35

	
T x 1	S x 1



FITTING OF ANTI-TOPPLE SAFETY STRAP


MONTAGE DE LA SANGLE DE SÉCURITÉ

ANTI-RENVERSEMENT

COLOCACIÓN CORREA DE SEGURIDAD ANTI-TOPPLE


STEP 1:

Fix screw through safety strap hole on the top panel of your furniture.




STEP 2:

Drill a hole on the wall and insert the wall plug.



STEP 3:

Fix screw through the safety strap in the wall plug hole.




NOTE: Wall fixings are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on bricks wall). You must use fixing devices suitable for the type of wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the product and that the fixing is safe and secure before use.

The straps and screws which to fix the strap on to the furniture are provided only.

HARDWARE LIST




STRAP (200mm) - 1 Pc



M3.5 x 25mm - 1 Pc

MAXIMUM LOADS CHARGES MAXIMALES / CARGA MAXIMA



This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

Ce meuble a été conçu pour supporter les charges maximales indiquées. En excédant ces limites de charge, le meuble pourrait devenir instable, s'effondrer, et/ou causer des blessures graves.

Esta unidad ha sido diseñada para soportar la carga máxima anotada. El exceder estos límites puede causar inestabilidad, colapsarse y/o causar serias lesiones.