

ASSEMBLY & INSTALLATION

Please read carefully and save these instructions, as you may need them at a later date.

IMPORTANT SAFETY INSTRUCTIONS: This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

GENERAL

Remove the lamp and from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

ASSEMBLY AND INSTALLATION

1. Position the Mounting plate (pre-assembled) on the wall at desired location and mark the place for plastic anchors to be installed.
2. Drill pilot holes on the marked spots and insert plastic anchors, attach the mounting plate to the plastic anchors and secure with wood screws.
3. Raise the backplate assembly to the wall, line up mounting screws with holes in backplate and secure with the mounting screws
4. Slide the SHADE over the SOCKET, fix with the SOCKET RING. Screw light bulb into the sockets and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating label, **MAXIMUM 40W**.
5. Plug the power cord into an outlet and turn on at switch.

