


Product Name:	Chestnut Finish Pine and MDF Wood Accent Round Table with Faux Rattan Shelf
SKU #:	WHIF2233

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Do not attempt to assemble or use the product if any parts are missing or damaged.

CARTON CONTENTS:


A	B	C	D	E	F
					
Table top	Leg	Shelf	Washer	Bolt	Allen Key
1PC	1PC	1PC	8PCS	8PCS	1PC

Tools required for assembly: Philips screwdriver (if using power tools, use with care).

Product Name:	Chestnut Finish Pine and MDF Wood Accent Round Table with Faux Rattan Shelf
SKU #:	WHIF2233


ASSEMBLY INSTRUCTIONS:

Step 1: Place the legs (B) upside down and fix them together in the notched crossbar as shown in the images below.




Product Name:	Chestnut Finish Pine and MDF Wood Accent Round Table with Faux Rattan Shelf
SKU #:	WHIF2233

Step 2: Attach the round top (A) to the top of the legs using the 4 x spacers (D) and screws (E). Allen wrench (F) can be used to tighten the screws. Do not overtighten, as this may cause stripping.




Step 3: Attach the bottom shelf (C) to the bottom section of the legs using the 4 x spacers (D) and screws (E). Allen wrench (F) can be used to tighten the screws. Do not overtighten, as this may cause stripping.



Product Name:	Chestnut Finish Pine and MDF Wood Accent Round Table with Faux Rattan Shelf
SKU #:	WHIF2233

Step 4: The table is now fully assembled. Gently shake the table to ensure all screws are tight. Tighten screws as needed.



WARNING: Do not sit, stand, or climb on this table. These actions could cause serious bodily injury and damage the furniture.