

Thank you for choosing. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control.

If you have any questions, comments or concerns, feel free to contact us

# CERAMIC BIRDBATH

Read assembly instructions carefully and follow the care instructions.



Save this document for future reference.

Select a smooth, level surface to place the birdbath.

No.	PARTS	QTY.
A	Bowl	1
B	Pedestal	1



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.



## CHOOSING A LOCATION

Before assembly, carefully choose the location of the birdbath. Select a flat, level surface. If placing the birdbath on a rough surface, such as on decorative rocks, we highly recommended using a large stepping stone or paver to prevent chipping and damaging the finish.

If you need to move the birdbath, remove the bowl from the pedestal before doing so; lifting the assembled birdbath by the bowl may result in permanent damage to both parts of the unit.

## ASSEMBLY

1. Gently place the pedestal in the desired location.
2. Align the notches on Bowl (A) with the grooves in Pedestal (B) and gently place the bowl onto the pedestal.
3. Gently but firmly twist the bowl to lock it onto the pedestal.

## CLEANING

Cleaning 1-2 times per week is recommended.

1. Empty the old, stagnant water.
2. Wash the bowl using warm water and a soft cloth.
3. Rinse the glass bowl thoroughly with running water.
4. Fill the bowl with fresh, clean water.

## ! SAFETY STATEMENTS & WARNINGS !

- Do not install the birdbath on uneven surfaces or loose soil.
- Disassemble the unit before moving; lifting by the bowl will damage the unit.
- Do not use a pressure washer, harsh chemicals, or abrasive materials to clean the birdbath.
- During freezing weather, empty the birdbath and store it indoors; prolonged exposure to winter weather as well as sudden temperature changes may cause the birdbath to crack or break.

**Any modification to the product or failure to follow recommended care will void the product warranty.**