WARNING

- Do not place the product on uneven ground. Make sure to place it on a flat, firm surface.
- Do not place it near open fire or other sources of high heat, and do not pour hot water on it. Doing so may lead to fire, burns for people and pets, or deformation of the product.
- The product is not suitable for pets whose heads are smaller than the gap between the grids of the panels.
- Not intended for use with children. Children should not be allowed to play in the pet pen.

ATTENTION

- Due to ages, breeds and sizes, personalities, and other individual differences, it is possible that some pets may get stuck in the gaps in the panels or may be able to escape from the pet pen.
- Do not apply too much force when moving or adjusting the product.
- Do not pinch your pet or fingers when opening or closing the pet pen.
- Do not move the pet pen with your pet inside.
- Be careful when using on easily damaged floors. Moving the pen too roughly could create scratches or nicks on the floor.
- Extended periods of use may cause discomfort for your pet. Please ensure your pet's physical needs are met.
- Collars and chains may get stuck on the pet pen. Use of these items while in the pen could lead to injury or accident.
- Make sure the pet pen door has been securely closed and locked, otherwise you pet may be able to escape.
- Some pets may be able to figure out how to open the pet pen door. In this case, please use a padlock.
- To avoid deformation or discoloration, please pay attention to the following:
- Do not use in places with direct sunlight or in hot and humid environments.
- Please wipe away any moisture, oil, or detergent on the product as soon as possible.
- Do not place anything wet or hot inside the product.

CLEANING AND MAINTENANCE METHOD


- Clean away dirt with diluted neutral detergent. Wipe away any remaining residue with a damp cloth.
- Do not clean with ethyl alcohol, gasoline, decolorizer or cleanser.
- Make sure to dilute the methylphenol solution or other sanitizers before use.

TO CUSTOMERS

- The company is not liable for injury, accident, or damage to your pet due to improper use.
- The company is not liable for injury, accident, or damage due to natural hazards or improper repair or modification of the product.
- Please dispose of product and packaging materials according to local regulations.

GENERAL INSTRUCTIONS

Thank you for purchasing this product. Please read these instructions carefully before use. Keep these instructions for future reference.




SPECIFICATIONS


OUTER DIMENSIONS (in/cm)	W 35.125" × D 35.125" × H 23.75"	W 60.75" × D 60.75" × H 23.75"
	W 89.2 × D 89.2 × H 60.3 cm	W 154.3 × D 154.3 × H 60.3 cm
MAIN ENTRANCE DIMENSIONS (in/cm)	W 15.35" × H 18.50"	W 15.35" × H 18.50"
	W 39.0 × H 47.0 cm	W 39.0 × H 47.0 cm
MATERIAL	PANEL, HANDLE: POLYPROPYLENE	RUBBER FOOT: RUBBER

• PRODUCT SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.



PLEASE CONFIRM THE FOLLOWING PARTS ARE INCLUDED BEFORE ASSEMBLING.
PACKAGING MATERIAL IS NOT MARKED. EXTRA HARDWARE MAY BE INCLUDED FOR CONVENIENCE





Panel with door (1) Panel with door (1)

Panel with no doors (3) Panel with no door (5)

Rubber feet (8) Rubber feet (12)

