





ASSEMBLY INSTRUCTIONS



WARNING !



Assembly the furniture on empty carton, carpet, or rug to prevent scratches or damage.




This furniture requires 1 people to assembly.

Make sure no parts are missing or damaged before assembly.

Board Identification

Not actual size



BOARD IDENTIFICATION

Not actual size




① x1




② x1



③ x1




④ x3




⑤ x1




⑥ x1




⑦ x1




⑧ x1



⑨ x1



⑩ x1




⑪ x4



⑫ x1



⑬ x1



⑭ x1




⑮ x1



⑯ x1

BOARD IDENTIFICATION

Not actual size



①7 x1

HARDWARE LIST



M6x12

A x22+2



M6x22

B x3




M6x30

C x3



M6x30

D x3



Ø3.5x12

E x8



F x10



Ø15x9.5

G x10



Ø6x30

H x8



Ø4x35


J x14+1



K x5




L x1



M x1



N x2




P x1


Cam Lock Fastening System

Insert the cam bolt into the hole first, then insert the cam lock and lock it.


1



2




3







The opening must point toward the edge of the board







4




STEP 1




STEP 2




STEP 3




STEP 4






STEP 5




STEP 6






STEP 7







STEP 8




STEP 9



STEP 10







STEP 11



	
M6x12	
A	x16




STEP 12




	
N2	x2

	
Ø3.5x12	
E	x4


STEP 13




STEP 14




STEP 15




STEP 16




STEP 17



STEP 18










Ø4x35

J	x 4
---	-----


STEP 19




STEP 20





STEP 21



STEP 22



STEP 23



FURNITURE CARE AND MAINTENANCE

Medium - Density Fiberboard and Particle board

Thank you for your purchase. We want your item to last as long as possible. To ensure the product gives you years of service, please refer to this care and maintenance guide.



MAINTENANCE

- Tighten all bolts and screws again within the first 2 weeks of assembly
- Check the tightness of all bolts every 2 months, tighten them if necessary



CLEANING

- Clean the surface of the MDF (medium - density fiberboard) or PB (particle board) with a lightly dampened cloth.
- Small amount of mild soap can be used if necessary
- Dry the surface immediately after cleaning.

⚠ DO NOT use bleach or alcohol detergent to clean the surface.

⚠ DO NOT apply wood treatment on parts made with MDF and PB.

Medium - density fiberboard and Particle board will swell and distort when suffer from water damage.

Make sure to dry the furniture immediately after cleaning