

HISUKOY

HISUKOY 2-Tier Rattan End Table

with Tempered Glass Top | Assembly & Care Guide

Model: HISUKOY-ET-001 • Brown



Important: Please read all safety warnings and assembly steps before use. Keep this guide for future reference. Retain it for the life of the product.

1. Safety Warnings

- Tempered glass can break under impact. Do not strike the glass top with hard or sharp objects. If the glass is chipped or cracked, stop using the table and dispose of it safely.
- Assemble the table on a soft, flat surface (such as a carpet or rug) to avoid scratching the glass and to protect the rattan.
- This product is intended for indoor use. Keep it away from direct moisture, prolonged sunlight, and heat sources.
- Children should not climb or stand on the table. Do not place excessive weight on the glass top; distribute items evenly.
- Check that all screws and washers are tightened before each use. Periodically re-tighten hardware as needed.
- Use the included tools only. If a power tool is used, set it to low torque to avoid stripping screws or damaging the frame.

California Proposition 65 Warning

WARNING: This product can expose you to chemicals including formaldehyde, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

2. Parts List

Lay out all parts and check against the list below before assembly. Hardware quantities are packed in the accessory bag included in the carton; confirm the actual count against the bag contents.

Ref	Part	Qty
A	Tempered glass top (17.7" square)	1
B	Rattan lower shelf (woven)	1
C	Solid wood legs (tapered)	4
D	Screws (long, for legs to frame)	As packed
E	Screws (short, for glass bracket)	As packed
F	Washers	As packed
G	Allen wrench / screwdriver	1
H	Assembly instructions (this sheet)	1

Note: Screw and washer counts vary by production batch. Use only the hardware supplied in your carton. Do not substitute with longer screws that could pierce the glass.

3. Assembly Steps

Step 1 — Attach the legs to the rattan lower shelf

Turn the rattan lower shelf (B) upside down on a soft surface. Align the four legs (C) with the pre-drilled holes at each corner. Insert a washer (F) then a long screw (D) through the leg into the frame. Hand-tighten loosely so the legs stand evenly.

Step 2 — Position the glass top

Carefully place the tempered glass top (A) right-side up on a protected surface. With help if needed, lift the leg-and-shelf assembly and set it onto the glass, aligning the frame brackets with the glass mounting points. Do not drag the glass.

Step 3 — Secure the glass

From underneath, insert a washer (F) and a short screw (E) through each bracket into the glass frame. Tighten with the included Allen wrench / screwdriver. Alternate sides as you tighten so the glass seats evenly without stress.

Step 4 — Final check

Turn the table upright on a level floor. Press gently on each corner to confirm stability. Fully tighten all screws. Wipe the glass with a soft, damp cloth before use.

4. Care & Maintenance

- Dust the rattan with a soft, dry cloth. For deeper cleaning use a slightly damp cloth and mild soap, then dry immediately.
- Clean the tempered glass with a glass cleaner and a lint-free cloth. Avoid abrasive pads that can scratch the surface.
- Keep the table away from standing water. Wipe spills promptly to protect the rattan and wood frame.
- Avoid placing hot items directly on the glass or rattan. Use coasters or trivets.
- Periodically check and re-tighten all hardware to keep the table stable and safe.

Customer Support

HISUKOY | For missing parts, replacement hardware, or questions about this product, contact our support team with your model number HISUKOY-ET-001. We are happy to help.

WARNING: This product can expose you to chemicals including formaldehyde, known to the State of California to cause cancer and birth defects or other reproductive harm. www.P65Warnings.ca.gov