


USER'S MANUAL

SWIVEL UPHOLSTERED BARSTOOL



Guide of Manual

- Thanks for your choice. **We will do our best to provide customer service for everyone.**
- Please check to make sure all parts are included as stated when you unpack. If there are parts missing or wrong, please contact us, **we will expeditiously provide reissue accessories, compensation or other services.**
- Instruction should be read carefully. But the manual may not cover every detail of all possible situations and steps. **Please contact us if further information and help are needed. We will respond in a timely manner.**
- **Please be patient that the other items are on the way if you buy more than one product.**

Warning

- It's kindly advised to assemble this product on a carpeted floor to protect it from being scratched.
- Small parts are included. Please keep the product away from children while assembling. Do not let children play or jump on the product. Do not stand on the item or use as a step ladder.
- Please pay attention to the sharp corners during assembly. We recommend the use of gloves to prevent the undesired injury.
- Prior to use, please check to see if there's any loosening screw or part. Make sure that each screw and part is correctly installed and securely fastened.
- It's unnecessary to use electric drill. Please at a low gear if you need.

Care and Maintenance

- Use a soft, clean cloth that will not scratch the surface when dusting.
- There' s no need to use furniture polish. If you need, test it first in an inconspicuous area. Using solvents of any kind on your furniture may damage the finish. Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately. Gently blot the spill with a soft clean cloth to avoid rubbing.

Further Advice about the Furniture Care

- It is best to keep your furniture in a climate-controlled environment.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
- Periodically (every 90 days) make sure the screws are fully tightened.








Max Weight Capacity

- **330 lbs [Do not stand on the item]**




Parts and Hardware List:





- Make sure all parts are in the package.
- "+" in below list indicates that additional pieces are replacement parts.
- Do not fully tighten anything until all screws, nuts, washers and bolts are in place.

Parts List

①x1pc Seat 	②x1pc Seat Frame 	③x2pcs Connecting Bar 	④x2pcs Connecting Bar 
⑤x2pcs Legs 	⑥x2pcs Legs 	⑦x1pc Turntable 	

Hardware List

Ax8+1pcs Screw  M6*20MM	Bx8+1pcs Screw  M6*45MM	Cx8+1pcs Screw  M8*70MM	Dx8+1pcs Washer 
Ex8+1pcs Gasket 	Fx1 Allen Wrench  M6	Gx8+1pcs Washer  M8	




1

When installed, the same numbered legs are on a diagonal rather than on the same side.

All the screws in this step only need to be screwed to 50%, not 100%.


C		x8
E		x8
F		x1
G		x8
		
50%		☒
100%		☐



2

First tighten the legs and connecting bar to 100%. Then tighten the legs and seat frame from 50% to 100%.


B		x8
D		x8
F		x1
		
50%		☐
100%		☒



3


Note: Rotate the turntable to cross and separate the upper and lower iron plates, aligning the four holes in the lower iron plate with the four screw holes on the wooden frame.

A		x4
F		x1
	50%	☐ X
	100%	☒ ✓



4

A		x4
F		x1
	50%	☐ X
	100%	☒ ✓



FINISHED

