



2 Door Base Cabinet

889142951643

889142951421



ASSEMBLY INSTRUCTIONS

Before You Begin: Phillips screwdriver required (Not Included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a clean surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.








Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision. To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Failure to detach this restraint before moving furniture may result in injury or damage.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE




PARTS

(1)X1  Top Panel	(2)X1  Bottom Panel	(3)X2 L R  Side Panel (L&R)	(4)X1  Door Stopper	(5)X1  Back Panel	(6)X1  Shelf	(7)X4  Leg	(8)X1  Right Door
(9)X1  Left Door	(10)X1  Door Trim						


HARDWARE

(A)X8  Wood Dowel M8 x 30mm	(B) Hardware Packet Contents (B1)X16 (B2)X16   Male Camlock Female Camlock		(C)X4  Metal Shelf Support	(D)X2  CSK Screw M4 x 32mm	(E) Hardware Packet Contents (E1)X4 (E2)X4 (E3)X4    JCBB Spring Washer Flat Washer M8 x 60mm		
(F)X1  Allen Wrench M5	(G)X4  Soft Close Hinges 7/8	(H)X27  CSK Screw M3.5 x 16mm	(I) Hardware Packet Contents (I1)X2 (I2)X4   Handle Handle Screw		Use if needed. See anti-tip kit packaging for instructions.  Anti-Tip Hardware		


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11






STEP 12



COMPLETED



DOOR ADJUSTMENT




Important:

This furniture includes an anti-tipping kit to help prevent tip-over accidents.

Use is recommended for safety, especially if children are present.

Use the anti-tipping kit as seen in the diagram below. Choose a suitable wall fixing that matches your wall style and then fasten the strap to the wall as shown using appropriate fixings.





Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please use this item on a stable, level surface only. All parts of the base should contact the flooring surface when in use.
- Do not use this item if any instability is detected.
- This item is intended as a cabinet only, do not climb, stand or sit on this item.
- Do not use this item as a TV stand.
- To prevent pinching or crushing injuries, please ensure fingers are away from the sides of the doors when closing.
- Do not push or pull this item to move it, team lift to reposition.
- The item is intended to be used indoors.
- For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please review and retain all assembly instructions, safety and quality guidelines and product warnings for future reference.
- For product longevity, product safety and product integrity, protect from wet or humid weather and store indoors in a dry location. For additional storage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.

Glass Door Storage Cabinet

889142951476
889142951469
889142951216
889142951209



ASSEMBLY INSTRUCTIONS

Before You Begin: Phillips screwdriver required (Not Included).

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.










Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision. To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Failure to detach this restraint before moving furniture may result in injury or damage.


DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE




PARTS

(1)X1  Top Panel	(2)X1  Bottom Panel	(3)X2  Side Panel (L&R)	(4)X2  Support Rail	(5)X1  Back Panel	(6)X4  Shelf	(7)X4  Leg	(8)X1  Right Door
(9)X1  Left Door	(10)X1  Door Trim						


HARDWARE

(A)X12  Wood Dowel M8 x 30mm	(B) Hardware Packet Contents (B1)X26  Male Camlock (B2)X26  Female Camlock	(C)X16  Metal Shelf Support	(D)X6  CSK Screw M4 x 32mm	(E) Hardware Packet Contents (E1)X4  JCBB M8 x 60mm (E2)X4  Spring Washer (E3)X4  Flat Washer		
(F)X1  Allen Wrench M5	(G)X8  Soft Close Hinges 7/8	(H)X53  CSK Screw M3.5 x 16mm	(I) Hardware Packet Contents (I1)X2  Handle (I2)X4  Handle Screw	Use if needed. See anti-tip kit packaging for instructions.  Anti-Tip Hardware		


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7




STEP 8




STEP 9




STEP 10




STEP 11



STEP 12



DOOR ADJUSTMENT




Important:

This furniture includes an anti-tipping kit to help prevent tip-over accidents.

Use is recommended for safety, especially if children are present.

Use the anti-tipping kit as seen in the diagram below. Choose a suitable wall fixing that matches your wall style and then fasten the strap to the wall as shown using appropriate fixings.



Quality and Safety Guidelines

- Please follow the static and dynamic weight capacity limits provided on this item. If you are unsure of the weight capacities for this product, email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please use this item on a stable, level surface only. All parts of the base should contact the flooring surface when in use.
- Do not use this item if any instability is detected.
- This item is intended as a cabinet only, do not climb, stand or sit on this item.
- Do not use this item as a TV stand.
- To prevent pinching or crushing injuries, please ensure fingers are away from the doors when closing.
- Do not push or pull this item to move it, team lift to reposition.
- The item is intended to be used indoors.
- For maintenance instructions and replacement parts, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please review and retain all assembly instructions, safety and quality guidelines and product warnings for future reference.
- For product longevity, product safety and product integrity, protect from wet or humid weather and store indoors in a dry location. For additional storage instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please visit www.theubiquegroup.com for our product warranty details or email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- Please inspect this product regularly to make sure there are no damaged or worn parts. Also inspect to make sure all hardware is tightened correctly and securely. For inspection instructions, please email us at customerexperience@theubiquegroup.com or call 866-552-2810.
- If any parts are damaged or worn, please stop using the product. Repair this product with manufacturer supplied parts only.