## **INSTRUCTION MANUAL**

Customer Service: 470-926-8618 321-946-6293



# Please keep this manual and product code number for future reference and for ordering replace ment parts if necessary.

#### **GENERAL INSTRUCTIONS**

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

#### **INSTALLATION OVER CERAMIC TILES**

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.

#### **NOTICE**

- Caulking: no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.


#### CARE FOR YOUR SHOWER DOOR

- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
  An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels andmetal parts looking new
- We recommend wiping the glass panels with a squeegee after each use.

### **Tools Required**

Spirit level	Tape measure	Power drill	Drill Bits	Silicone Gun	
Screw driver	Pencil	Hacksaw	Rubber hammer	Safety glasses	

## **Detailed Diagram of Shower Enclosure Components**



NO.	Name	Picture	Qty	NO.	Name	Picture	Qty
1	Guide Rail	F	1	7	Towel Bar	<u></u>	1
2	Sliding Door		2	8	Roller		4
3	Wall Profile		2	9	Towel Bar	<b>Ø</b>	1
4	Screw ST4x30		4	10	Bottom Profile	Ţ	1
5	6mmWall Plug		4	11	Guide Block		1
6	Anti Collision Block	<b>P</b>	4	12	Sealant Strip	7	1

