









Outdoor Wicker Table



PART LIST


 Wicker Top		 Side Panel	
A	1pc	B	2pcs
 End Panel			
C	2pcs		

HARDWARE LIST


 Bolt(M6mm*30mm)		 Washer(M6mm)	
D	12pcs	E	12pcs
 Allen Key(M6mm)		 Adjustable Leveler	
F	1pc	G	4pcs

Step 1. Lay wicker Top (A) on a flat surface with underside facing up. Attach 1PC of Side Panel(B) to Top (A), 1PC of End Panel (C) to Side Panel (B) & Top (A) using Bolts(D), Washers(E) and Allen Key (F).


NOTE: Do not fully tighten bolt until all bolts are in place.



Step 2. Repeat Step 1 to attach 1 pc of Side Panel(B) to Top (A), 1pc of End Panel (C) to Side Panel (B) & Top (A)



Step 3. Screw the Adjustable Levelers (G) into the pre-drilled holes, to the desired position, on the bottom of the table.



Step 4. Turn the table upright.

