


LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

Thank you for purchasing the LONGSLOW ADJUSTABLE RADIATOR COVER.
Please read the instructions carefully to ensure safe operation of the product.



Size:Maximum L208xW20.9xH83.2cm
Minimum L151.8xW20.9xH83.2cm

PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction.

Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.


CAUTION: There are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking hazards.

Tool Required




LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS


Fully closed size:



Fully extended size:

















LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS



LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS


Parts

① 	② 	③ 	④ 
Description: Top panel Qty: 1PC	Description: Left Top panel Qty: 1PC	Description: Right Top panel Qty: 1PC	Description: Left Side panel Qty: 1PC
⑤ 	⑥ 	⑦ 	⑧ 
Description: Right Side panel Qty: 1PC	Description: Left Front panel Qty: 1PC	Description: Right Front panel Qty: 1PC	Description: Middle Front panel (Left) Qty: 1PC
⑨ 	⑩ 	⑪ 	⑫ 
Description: Middle Front panel (Right) Qty: 1PC	Description: Horizontal panel Qty: 2PCS	Description: Horizontal panel Qty: 2PCS	Description: Middle Horizontal panel Qty: 2PCS
⑬ 	⑭ 		
Description: Slats Qty: 29PCS	Description: Slats Qty: 4PCS		

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS


Fittings(to scale)

Ref	Dimensions	Qty
A	Cam bolt (6x35mm)	20
B	Wood dowel (6x30mm)	20
C	Cam (15x10mm)	20
D	Screw (5x12mm)	74
E	Screw (6x20mm)	4
F	Screw (6x27mm)	4
G	Screw (4x40 mm)	4
H	Screw (6x25mm)	4



(Not to scale)


I	Wall plug	4
J	Wall Bracket	2
K	L-shaped bracket	2



LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS



Layout Parts on Soft Surface

Lay out all parts on a soft surface i.e. Rug, Carpet or Packaging Carton





CAUTION: There are many small components used in the construction of this product. Please keep these components away from young children whilst assembling this product. If you keep the fittings in a bowl during assembly you will be less likely to lose them!

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS



STEP 1	Parts Required
	⑥ Left Front panel ×1 ⑦ Right Front panel ×1 A Cam bolt (6x35mm) ×10
STEP 2	Parts Required
	④ Left Side panel ×1 ⑤ Right Side panel ×1 B Wood dowel (6x30mm) ×4 C Cam (15x10mm) ×6

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS



STEP 3	Parts Required
	⑩ Horizontal panel×2 ⑪ Horizontal panel×2 B Wood dowel (6x30mm) ×8 C Cam (15x10mm) ×4

STEP 4	Parts Required
	⑬ Slats ×18 ⑭ Slats ×2 D Screw (5x12mm) ×44


LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

STEP 5	Parts Required
	② Left Top panel ×1 ③ Right Top panel ×1 A Cam bolt (6x35mm) ×6
STEP 6	Parts Required
	C Cam (15x10mm) ×6


LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

STEP 7	Parts Required
	⑧ Middle Front panel (Left) ×1 ⑨ Middle Front panel (Right) ×1 A Cam bolt (6x35mm) ×4
STEP 8	Parts Required
	⑫ Middle Horizontal panel ×2 B Wood dowel (6x30mm) ×8 C Cam (15x10mm) ×4

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

STEP 9	Parts Required
 The diagram shows an isometric view of the radiator cover assembly during Step 9. A base plate (8) is being secured with screws (12) into a frame (9). A set of slats (13) is being installed across the frame. Two additional slats (14) are shown being positioned at the ends of the assembly. The text 'D x 30' is written above the slats, indicating the screw size. The text '13 x 11' is written next to the slats, indicating the quantity. The diagram is labeled with circled numbers 8, 9, 12, 13, and 14.	⑬ Slats ×11 ⑭ Slats ×2 D Screw (5x12mm) ×30






LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

STEP 10	Parts Required
Assembly note: This step is easier with two persons.  Maximum To ensure proper alignment with the holes, lift the both side panel slightly while tightening screws E .F and H. The L -shaped bracket (part K) is to be used to adjust the product size accordingly to your needs. This manual only displays the installation methods for changing the maximum and minimum dimensions of the product. 	E Screw (6x20mm) ×4 F Screw (6x27mm) ×4 H Screw (6x25mm) ×4 K L-shaped bracket ×2


LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

	Parts Required
Assembly note: This step is easier with two persons. Minimum To ensure proper alignment with the holes, lift the both side panel slightly while tightening screws E . F and H. The L -shaped bracket (part K) is to be used to adjust the product size accordingly to your needs. This manual only displays the installation methods for changing the maximum and minimum dimensions of the product.	E Screw (6x20mm) ×4 F Screw (6x27mm) ×4 H Screw (6x25mm) ×4 K L-shaped bracket ×2

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

STEP 11	Parts Required
Position the radiator cover against the wall that it will be fastened to and using a pencil, mark the position of the screw holes onto the wall. Drill where the holes have been marked and insert the wall plugs, ensuring the edge is flush with the surface of the wall.  Wall fixing dimensions  	G Screw (4x40 mm) x 4 I Wall plug x4 J Wall Bracket x2

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS


STEP 12	Parts Required
 1 2 wall	

LONGSLOW ADJUSTABLE RADIATOR COVER ASSEMBLY INSTRUCTIONS

Complete Assembly

Your LONGSLOW ADJUSTABLE RADIATOR COVER is now completely assembled.


Periodically check to ensure that the components are in their proper position and free from damage.
Also make sure the connectors are tight and secure



Supplied by : GFW THE FURNITURE WAREHOUSE
Waterside Distribution Centre
Waterside Business Park
Johnson Road
Lancashire
BB3 3RT

www.gfwlimited.co.uk

Keep instructions for future reference.



Represented by:
Authorised Rep Compliance Ltd 71
Lower Baggot Street
Dublin
D02 P593
Ireland
www.arccompliance.com