





***IMPORTANT* Due to vibration during shipping, the hands on the clock may move and fall off track.**

Please note that the clock hands must not touch, in order for the clock to keep accurate time. You must have a 2mm - 1/8 inch gap between the 2 clock hand (As shown in photo provided).

If the clock hands have moved during shipping, please read the section troubleshooting on the back of this page.


If the clock hands are bent and are unable to straighten, please contact us and we will quickly send you replacement clock hands.



Battery :

4. Insert the Battery into the back of the clock. Pay attention to the +,- direction. The movement may be damage if the battery is not properly inserted.
5. Turn the knob on the left side in a counterclockwise direction to adjust the time.
6. Replace the battery once the battery runs out of power.

Note: Only use standard Alkaline batteries in your new clock. NOTE: do not use rechargeable or extra powerful batteries (such as Duracell Extra Power) as it will damage the clock mechanism.




Troubleshooting:

If you notice your clock hands are not moving, please follow these five simple and quick steps below; or watch our helpful video using the link provided:

1. Begin by slowly removing the small pin or screw (holding clock hands).
2. Remove the top hand (largest one) completely off clock.
3. Push the small hand, still on the clock, down until you feel it "click" into place. It should feel secure.
4. Repeat step for the longer hand. It should also click into it's correct place on the track.
5. Once you have put the two hands on securely, install the small pin (that looks similar to a push pin) to secure the hands down. For our Larger clock, it will look like a screw.

Finally, rotate both hands twice, counter- clockwise for a full 360 degrees and set the time.



**** For your Convenience:** We have included an extra pin to hold down the clock hands as it sometimes falls out of place during shipping** -- The additional pin is located in a plastic bag attached to the back of your clock. **

ATTENTION

Surfaces of our Wood Wall Art:

Please note that your wood wall art was created especially for you when you ordered it. All our wood wall art is made with 100% real pine wood, as each panel is natural wood this may cause the surface to be slightly bent. This makes every piece unique and is the real beauty of our wood artwork.

Drying time of our Wood Wall Art:

To ensure you receive your order as quickly as possible, we package and ship immediately after it is created. Due to the natural properties of pine wood, the drying time of the ink used to create your wood artwork is slightly longer than a metal or canvas wall art.

You may notice an ink odor upon opening your artwork. The ink we use in the creation of the artwork is Eco-friendly and NON-TOXIC. If the odor is unpleasant to you, please place the wall art in an open space where it can air out. The ink odor should be completely gone within 2-3 days of un-wrapping you order.