

IMPORTANT SAFETY NOTICE

- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce risk of electric shock. This plug will fit in a polarized outlet only one way. If it doesn't fit fully in your outlet, reverse the plug. If it still doesn't fit, contact a qualified electrician. **NEVER** use with an extension cord unless the plug can be fully inserted.
- Do not plug your lamp in until assembly is completed.
- Periodically check to make sure that all connectors (bolts, screws etc.) are tight.

ASSEMBLY INSTRUCTIONS

Before you begin, please review all parts and hardware before you discard any packaging. Refer to the image and key below to identify parts needed.

Each lamp includes:
A) Base
B) Lamp Body
C) Lamp Body
D) Lamp Body
E) Top tube
F) Saddle
G) Socket
H) Harp
I) Lamp shade
J) Finial

Step 1

Screw the Top tube [E] onto the Lamp body [D].

Step 2

Screw the Lamp body [D] onto the Lamp body [C].

Step 3

Screw the Lamp body [C] onto the Lamp base [B].

Step 4

Screw the Lamp body [B] onto the Lamp base [A].

Be careful not to twist the power cord and tighten securely

Step 5


Squeeze both legs of the harp [H] together and guide them into the saddle [F].

Step 6

Screw a light bulb (included) into the socket [G]. *Note: We recommend no higher than a 100-watt bulb. If you're using an LED bulb, no higher than 12 watts.*

Step 7

Place shade [I] over the harp [H] and screw on the finial [J] to secure the shade.



Step 8

Put the lamp on a level surface to make sure that all pieces are stable.