


# Sky inflatable tent 9m<sup>2</sup>

## JFG046BG INSTRUCTION MANUAL



### Setting up & Folding

#### Setting up

- The site shall be flat and clear.
- Open the package, spread and stretch the tent, find the nozzle ( black), and inflate the tent with the inflator until the red pressure relief valve (PRV ) starts to release pressure.
- Fix the tent pegs on the ground at a 45 degree angle, tighten the rope on the pegs.
- Adjust the tent to make it smooth and nice looking.

#### STEP1



1. Spread out the tent cloth

#### STEP 2



2. Nail the four corners of the tent cloth with ground nails


#### STEP 3



3. The inflator shall be connected for inflation until the red pressure relief valve (PRV) starts to release pressure

#### STEP 4

4. Fix the tent pegs at a 45 degree angle and tighten the rope on the pegs.




#### Folding

- Pull out the pegs with hammer, untie the rope and place the pegs in the bag.
- Open the nozzle to deflate the tent, then fold it and place it in the bag.



#### STEP 1

1. Pull out the pegs and untie the rope




Turn left to deflate the tent

#### STEP 2

2. Turn the nozzle to the left to deflate

### Product & fittings



9m<sup>2</sup> Inflatable tent



Inflator



Repair accessories



18 tent pegs



Wind rope

### ATTENTION:

1. Please check the manual carefully and make sure you have received all the parts.
2. If there is any missing, please let us know the letter of the parts you need.
3. If there is any damage, please send clear photos to us, we will check and offer you best solution soon.

made in China