


ATTENTION
All parts are
inside the Headboard


ASSEMBLY INSTRUCTION

ITEM : B10-QB/B11-QB/B12-QB B10-FB/B11-FB/B12-FB		
NO	PART LIST	QTY
1	HEAD BOARD CUSHION	1pc
2	RIGHT HEAD BOARD LEG (WITH "R" LABEL)	1pc
3	LEFT HEAD BOARD LEG (WITH "L" LABEL)	1pc
4	FOOT BOARD CUSHION	1pc
5	FOOT BOARD LEG	2pcs
6	(left) SIDE RAIL	2pcs
7	(right) SIDE RAIL	2pcs
8	CLEAT	4pcs
9	SIDE RAIL SUPPORT	2pcs
10	SLAT	4pcs
11	SLAT SUPPORT (with adjustable feet)	4pcs
NO	HARDWARE LIST	QTY
A	JCBB SCREW M8 x 20mm	8pcs
B	JCBC SCREW M6 x 35mm	28pcs
C	JCBC SCREW M6 x 50mm	6pcs
D	SPRING WASHER M6 x 12mm	30pcs
E	FLAT WASHER M6 x 19mm	30pcs
F	SCREW M4 x 32mm	8pcs
G	L - KEY M5 x 65mm	1pc
H	L - KEY M4 x 100mm	1pc


STEP 1




STEP 2



STEP 3




STEP 4




NOTE: AFTER A FEW DAYS OF ASSEMBLY, IT WILL HAVE ACCLIMATIZED TO THE ENVIRONMENT. PLEASE TIGHTEN ALL HARDWARE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.

ASSEMBLY INSTRUCTION


STEP 5



STEP 6



STEP 7 (DONE)



NOTE: AFTER A FEW DAYS OF ASSEMBLY, IT WILL HAVE ACCLIMATIZED TO THE ENVIRONMENT. PLEASE TIGHTEN ALL HARDWARE. CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.