





Ax1 	Bx1 	Cx1 	Dx1 
Ex4  M6x50MM	Fx4  M6x13MM	Gx8 	Hx1 
Ix4 	Jx8 		

SPARE (Ersatzteile)

Ex1  M6x50MM	Fx1  M6x13MM	Gx1 
Ix1 	Jx1 	

STEP 1



STEP2

