



# 4pc Tin Burner Cover Set

## Use/Manual

HEAD QUARTERS  
22880 GLENN DRIVE STE. 150  
STERLING, VA 20164  
WWW.RESTONLLOYD.COM  
INFO@RESTONLLOYD.COM  
1-844-755-1972



### SET

This set contains four total covers. Two which are eight inches in diameter and two ten inch covers in diameter. Please measure your stove to make sure this will fit your stovetop. These are a general size and will not cover burners which are for grilling, odd shaped, or gas burners. Each cover flares out so the bottom dimensions are slightly larger.

### USE

These burner covers are use to add decor to your stovetop and camouflage stains and spills. They are not to be used as a trivet for hot pans. Under any kind of heat from your stove even the lowest temperature, the covers will melt or distort.

### MATERIAL

These covers are made of a light weight tin material with a light paint coating. These are not suitable to eat off of or for food storage. This is a decor kitchen item.

### CLEANING

For best results use a damp cloth to wipe clean. They are not dishwasher safe. Due to the rolled edge of the covers it's not recommended that you soak the covers in water (to avoid getting water trapped in the rolled tin). You can use any mild dish soap to clean the covers but avoid using any abrasive cleaners or sponges.