

24
MONTH
Product Warranty



Your appliance comes with a standard 12 month warranty, however, with registration you can extend this to 24 months to enjoy even more piece of mind.

Simply visit www.MyVQ.com/pages/warranty to register your product for this extended warranty.

Why not complete the set with a matching Toaster?



If you do need any assistance with this appliance during your warranty period contact the VQ support team:



| support@MyVQ.com



Need Help?



www.MyVQ.com



support@MyVQ.com

Imported by:



Englewood Marketing Group, 1471 Partnership Drive, Green Bay, Wisconsin, 54304, United States.

Manufactured by:

Sourcing Boutique HK Ltd, 21st Floor, The Phoenix 23 Luard Road, Wan Chai, Hong Kong.

LAURA ASHLEY

SINCE 1953

by  MyVQ.com

Stove Top
Kettle



STOVE TOP KETTLE
USE & CARE GUIDE



MyVQ.com

Stove Top Kettle

My VQ Stove Top Kettle is an investment that will prove its worth every time you use it. When properly cared for, your VQ Stove Top Kettle will give you countless years of service and pleasure. Follow the use and care suggestions in this leaflet to preserve and maintain the kettle's original beauty.

ESSENTIAL PRECAUTION

Never leave your VQ Stove Top Kettle on high heat. A low to medium heat setting is recommended. To boil water in your kettle, a medium-high setting is sufficient. Never set the burner on high. Never leave your VQ Stove Top Kettle or any kettle empty over a hot burner. Doing so can ruin the kettle and cause damage to the stovetop.

EASY MAINTENANCE

Immediately after each use, fill the kettle with warm water and liquid dish detergent; let stand until lukewarm. Use a sponge or soft cloth to remove any remaining residue. Do not use steel wool or other metal pads that make coarse scratches. Rinse thoroughly and dry immediately for a flawless finish. Never wash your VQ Stove Top Kettle in a dishwasher.

TO REMOVE STAINS

Calcium in your water may leave a multicoloured stain. This is from a harmless deposit and can be removed with a little warm vinegar.

TO REMOVE BURNER STAINS

Stains on the outside bottom (not sides) of your VQ Stove Top Kettle can be removed with an oven cleaner. Follow the manufacturer's directions and spray or brush the cleaner on only the outside bottom of the kettle. Rinse thoroughly after cleaning.

CAUTION: Detergent fumes can be irritating. Carry out this procedure under a hood with an exhaust fan or in a well-ventilated room.

USING OVER A GAS BURNER

When heating over a gas burner, make certain the flame touches only the kettle bottom. If the flame comes up the sides, energy is wasted and the sides of the kettle may become permanently discoloured.

IMPORTANT NOTE: Your VQ Stove Top Kettle has exceptionally high thermoconductivity, and even a low setting on some gas burners will overheat. An inexpensive gas "flame-tamer" placed between the burner and the bottom of the kettle solves this problem. Flame-tamers are readily available at most hardware stores.

BEFORE FIRST USE:

Remove any labels/hang tags.

2. Wash in warm soapy water and rinse thoroughly.

USAGE INSTRUCTIONS:

3. Fill the kettle only up to the MAX FILL mark. **DO NOT OVERFILL.**

4. Kettle should be placed on a burner no larger than the bottom of the kettle.

5. When you hear the whistle, turn off the burner, remove the kettle from the burner and wait for approximately 20 seconds until the water ceases to boil. **DO NOT POUR BOILING WATER.**

We recommend using a pot holder or mitt when pouring. Handles may become hot, especially if other pots are being heated on the range.

6. Do not attempt to pour from the kettle unless the lid is snapped closed/locked in place.
7. Depending upon where you live, some water may have excessive amounts of minerals in it. Periodically remove mineral deposits by boiling water with 2 tablespoons of baking soda and the juice of half a lemon. Do not use steel wool or harsh abrasives to clean your kettle.
8. Do not place an empty Kettle on a hot burner.
9. **NEVER ALLOW YOUR VQ STOVE TOP KETTLE TO BOIL DRY.** A kettle that has been boiled dry may be damaged and should not be used. Electric burners may also be damaged when a kettle is boiled dry.
10. Stainless steel kettles should be cleaned with a soft cloth. Stainless steel cleaners may be used on the exterior surfaces of your kettle.
11. Those living in areas with high mineral content water may need to use a commercial lime removal product. Follow package directions carefully to avoid damaging your Kettle.
12. **NEVER** wash your VQ Stove Top Kettle in a dishwasher. Dishwasher detergents and high temperatures can damage the finish of your kettle and cause it to deteriorate more quickly. Instead, wash your kettle by hand using warm, soapy water and a soft cloth, and dry it thoroughly after each use.