

# USE THE INSTRUCTION MANUAL



## HOW TO USE

- 1.To ensure strong suction,please fully charge the vacuum before using it.
- 2.Slide the switch forward to absorb debris,crumbs, sands,dust,hair and more.
- 3.Make sure the mouth parallel with the place you areabout to clean for the most efficient cleaning.
- 4.Switch off the vacuum after finishing cleaning work.

## CLEAN THE FILTER

1. Remember to clean the filter after every use to keep strong suction.
2. Separate the dust cup and motor to pour all trash out of dust cup.
3. Wash the filter with the help of detergent and a brush.
4. Let the filter dry in a ventilated area but not in direct sunlight for very long.

## MAINTENANCE

- Switch off the vacuum when finishing using vacuum
- Give the vacuum a 2-minute rest after every 15 minutes of continual use.
- Clean and dry out the filter & dust cup after each use
- Store all parts in the carrying case to keep them organized and then put the carrying case in a dry and cool place.
- Keep every part of the vacuum away from the nigh-heat things and strong sunlight

## HOW TO CHARGE

- 1.Please connect the charger to the vacuum,then plug t into socket.
- 2.The light will turn "green"from "red"when the vacuum is fully charged.

## HOW TO DEAL WITH COMMON MALFUNCTION

Malfunction	Probable Reasons	Solutions
Weakened Suction	The filter is blocked.	Clean the filter in time.
	Power runs out.	Charge the vacuum.
Charging Problems	Defective charger or battery	Contact Customer Service

## PRODUCT DETAILS



- ① Release Button
- ② LED Light
- ③ ON/OFF Switch
- ④ Light Switch
- ⑤ Vent
- ⑥ Motor
- ⑦ Filter
- ⑧ Dust Cup
- ⑨ Charge Adapter
- ⑩ Crevice Nozzle Tool
- ⑪ Brush Tool
- ⑫ Tiny Tool
- ⑬ Long Straw

