


ASSEMBLY INSTRUCTION

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and cout all parts and metal harware. Compare with all parts list to be sure all part are persent. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.


*****Do not fully tighten screws until fully assembled*****

	COMPONENT PARTS	
DESCRIPTION	PARTS NAME	Q' TY (PCS)
1	WOOD TOP WITH DRAWER 	1
2	RIGHT LEG 	1
3	LEFT LEG 	1
4	POST 	1


HARDWARES REQUIRED



A  PLUG - 2 PCS

B  WOOD DOWEL - 4 PCS

C  BOLT 1/4",28MM - 4 PCS

D  BOLT 1/4",38MM - 2 PCS

E  FLAT WASHER 1/4",16MM - 4 PCS

F  FLAT WASHER 1/4",13MM - 2 PCS

G  LOCK WASHER - 6 PCS


H  ALLEN WRENCH - 1 PC

Attention:

*** Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.

How to assemble:

STEP 1 :



STEP 2 :

