KRAND

Retain the instructions for future ref.

Toddler Rocking Reindeer

ASSEMBLY INSTRUCTIONS

ITEM #RT241021

HARDWARE

A.Hex Screw×11PCS



7*60mm

B.Phillips screws ×2PC




3.5*45mm

C.Allen Wrench×1PC





PARTS LIST



STEP1

As shown in the diagram below, use 4 A- the Hex Screws to attach parts 5 and 6.
This step does not require tightening 4 A- the Hex Screws, ensuring that two parts 5 have limited adjustment angles for future steps.







Attention: STEP1 does not require 100% tightening of 4 A. Hex screws until all steps are fully installed.


STEP2

As shown in the diagram below, use 1 B- the Phillips screw to fix parts 1 and 2.





Phillips screwdriver is required for steps shown above . Keep it carefully and away from children after assembly .



KRAND

Retain the instructions for future ref.


Toddler Rocking Reindeer

ASSEMBLY INSTRUCTIONS

ITEM #RT241021

STEP3

As shown in the diagram below, use 3 A- the Hex Screw to fix head and backrest.




***Insert part 3 into the groove of part 4.**

***Insert the head into the square slot of part 4.**

***Fix them with C. the Allen Wrench.**

STEP4

As shown in the diagram below, use 4 A- the Hex Screw to fix parts, then use 1 B- the Philips screw to fix the rest.



Phillips screwdriver is required for steps shown above . Keep it carefully and away from children after assembly .

Reminder: If you have any issues with the product please e-mail us for support at **scg4586@yeah.net.**

IMPORTANT INFORMATION-PLEASE READ FIRST:

ALL OF OUR WOOEDN ITEMS ARE HANDCRAFTED,HAND ASSEMBLED,AND HAND PAINTED.EACH ONE IS UNIQUE.SLIGHT INPERFECTIONS MAY OCCUR AND ARE NOT MANUFACTURING DEFECTS.EACH ITEM HAS BEEN PAINTED WITH VERY DURABLE PAINT THAT IS BOTH LEAD AND CHROMATE FREE AND SAFE FOR CHILDREN.HOWEVER,IT WILL NOT WITHSTAND ABNORMAL ABUSE AND WITH IMPROPER USE,IT COULD CHIP. PLEASE NOTE THAT WE DO NOT WARRANTY AGAINST THE USE OF PERMANENT MARKERS,NON-WATER-BASED PAINTS,CRAYONS,OR WASHABLE MARKERS.SOME OF THESE ITEMS CONTAIN PERMANENT COLOR DYES THAT COULD DAMAGE THE SURFACE.

WARRANTY

IMPORTANT:EVIDENCE OF ORIGINAL PURCHASE IS REQUIRED FOR WARRANTY SERVICE.
LENGTH OF WARRANTY:90 DAYS FROM DATE OF PURCHASE.
THIS WARRANTY COVERS EDFECTS THAT WERE A RESULT OF THE MANUFACTURERS PRODUCTIONS.YOU SHOULD CAREFULLY INSPECT THE CONDITION OF THE PRODUCT PRIOR TO ASSEMBLY.THIS WARRANTY IS INVALID IF THE PRODUCT IS DAMAGED OR NOT MAINTAINED PROPERLY.

Development zone of Heilin Ganyu section Lianyungang Jiangsu Pov.China.
Powered by lianyungang yubao I/E CO.,LTD
Kids Furniture Research And Development
www.krand.com.cn
K R A N D

CAUTION:

Adult assembly required.
Hardware contains small screws with sharp points.Keep unassembled parts.

MAINTENANCE:

-Placing on flat and level surface while using.
-Ensure the produt continue to function properly and safely by regularly checking the hardware and tightening when necessary.

⚠WARNING:

Choking Hazard： Small parts
Not for children under 2 years and put it to somewhere children can’t reach.

KRAND

Retain the instructions for future ref.


Toddler Rocking Reindeer

ASSEMBLY INSTRUCTIONS

ITEM #RT241021

STEP3

As shown in the diagram below, use 3 A- the Hex Screw to fix head and backrest.




***Insert part 3 into the groove of part 4.**

***Insert the head into the square slot of part 4.**

***Fix them with C. the Allen Wrench.**

STEP4

As shown in the diagram below, use 4 A- the Hex Screw to fix parts, then use 1 B- the Philips screw to fix the rest.



Reminder: If you have any issues with the product please e-mail us for support at **scg4586@yeah.net.**

IMPORTANT INFORMATION-PLEASE READ FIRST:

ALL OF OUR WOOEDN ITEMS ARE HANDCRAFTED,HAND ASSEMBLED,AND HAND PAINTED.EACH ONE IS UNIQUE.SLIGHT INPERFECTIONS MAY OCCUR AND ARE NOT MANUFACTURING DEFECTS.EACH ITEM HAS BEEN PAINTED WITH VERY DURABLE PAINT THAT IS BOTH LEAD AND CHROMATE FREE AND SAFE FOR CHILDREN.HOWEVER,IT WILL NOT WITHSTAND ABNORMAL ABUSE AND WITH IMPROPER USE,IT COULD CHIP. PLEASE NOTE THAT WE DO NOT WARRANTY AGAINST THE USE OF PERMANENT MARKERS,NON-WATER-BASED PAINTS,CRAYONS,OR WASHABLE MARKERS.SOME OF THESE ITEMS CONTAIN PERMANENT COLOR DYES THAT COULD DAMAGE THE SURFACE.

WARRANTY

IMPORTANT:EVIDENCE OF ORIGINAL PURCHASE IS REQUIRED FOR WARRANTY SERVICE.
LENGTH OF WARRANTY:90 DAYS FROM DATE OF PURCHASE.
THIS WARRANTY COVERS EDFECTS THAT WERE A RESULT OF THE MANUFACTURERS PRODUCTIONS.YOU SHOULD CAREFULLY INSPECT THE CONDITION OF THE PRODUCT PRIOR TO ASSEMBLY.THIS WARRANTY IS INVALID IF THE PRODUCT IS DAMAGED OR NOT MAINTAINED PROPERLY.

Development zone of Heilin Ganyu section Lianyungang Jiangsu Pov.China.
Powered by lianyungang yubao I/E CO.,LTD
Kids Furniture Research And Development
www.krand.com.cn
K R A N D

CAUTION:

Adult assembly required.
Hardware contains small screws with sharp points.Keep unassembled parts.

MAINTENANCE:

-Placing on flat and level surface while using.
-Ensure the produt continue to function properly and safely by regularly checking the hardware and tightening when necessary.

⚠WARNING:

Choking Hazard： Small parts
Not for children under 2 years and put it to somewhere children can’t reach.