




Folding Dining Table

Assembly Instructions

CZ090




Assembly Overview



Parts List


1 Table assembly

Qty: 1



2 Base support

Qty: 2




Hardware List

A Hex socket screw

M8 × 65MM


4 + 1 PCS



B Flat washer

M8 × Ø19MM


4 + 1 PCS



C Spring washer

M8


4 + 1 PCS



E Adjustable foot

M8 × Ø40MM × 22mm


Qty: 2



F Pad

Ø25 × 3MM

Qty: 4




Tool

D Hex key

M5 × 100MM


Qty: 1



Choose the Correct Screws


Using the correct screws helps prevent damage to components.

Example




Incorrect

Oversized screws can crack the panel.



Correct


Use the correct size screws.



Step 1

Place table assembly (1) on its side; handle the folding side panels carefully. Attach base supports (2) using A, B and C with tool D.

Hardware: A × 4, B × 4, C × 4 Tool: D × 1




Step 2

Screw adjustable feet (E) into position as shown.

Attach pads (F) to base supports (2) as illustrated.

Hardware: E × 2, F × 4




Step 3

Raise one semicircular tabletop panel and swing out the support.

Fit the locating dowels underneath the panel into the oval holes

at the top of the support. Rotate the adjustable feet to level the table.



Step 4

Fully extend the tabletop by opening the other side following the same procedure as Step 3.

