

Contains

5 x 35" x 48" Jumbo Space Saver Vacuum Bag
6 x 26.5" x 39.5" XL Space Saver Vacuum Bag
6 x 21.5" x 33.5" Large Space Saver Vacuum Bag
8 x 18" x 22.5" Medium Space Saver Vacuum Bag
1 Manual Pump

Warning

- Most of air leak problems are due to zipper seal not closed fully and tightly allowing air to escape. Please make sure zipper is closed tightly and firmly 3 times.
- Item should be completely dry before packing
- Do not store sharp objects inside the bag
- Use the vacuum bags on a clean and even surface
- Do not overfill the bag! Fill bag until line is reached

Warranty

1. Warranty is not covering misuse. Please read instructions and warnings carefully.
2. Basic warranty is for 30 days.
3. A Lifetime Warranty is available free for 30 days by registering online at: www.Home-Complete.com/Register

For Customer Support and Feedback

Email: support@Home-Complete.com

Space Saver Vacuum Bag Instruction

1. PACK your bedding, clothing, gear—any items you want to store and/or protect. Items should be completely dry before packing, and Vacuum Packs should not be filled above the fill line.

2. CLOSE bag at zipper, and then seal it securely by sliding the zipper slider across the bag 3 times.

3. VACUUM OUT THE AIR using a vacuum cleaner. Remove the cap and insert your vacuum hose to remove the air. The one-way valve fits any vacuum hose. Simply turn your vacuum on and it's done! If Vacuum Pack inflates, go back and repeat steps 1&2.

4. RE-OPEN & RE-USE. Gently unzip the bag and carefully remove your items. Do not tear or puncture the bag. Vacuum Packs can be used again and again!

