

OUTDOOR WATER FOUNTAIN USER MANUAL

User Manual (English)

Model / SKU: _____ Color/Finish: _____ Date: _____

WHAT'S IN THE BOX

- Fountain body
- Fountain back cover
- Nozzle (hose-to-pump connector)
- Submersible water pump
- Two assembly parts for the hand-pump fountain
- Rainproof AC adapter / transformer + power plug (GFCI required)
- User manual



IMPORTANT SAFETY

- Use a covered Class A GFCI-protected outdoor receptacle.
- Unplug before moving, cleaning, or servicing.
- Keep the pump fully submerged. Never run the pump dry.
- Keep the adapter/transformer dry and elevated off the ground. Keep all connections dry.
- Do not use damaged cords, plugs, or parts.
- Tip: Create a drip loop on the cord before it reaches the outlet.



SETUP & OPERATION

Keep the water level above the pump at all times.



Step 1. Unpack & Position

Place on a flat, stable surface near a GFCI outlet. Keep upright.



Step 2. Inspect Parts

Confirm parts are included. Do not use if cracked or damaged.



Step 3. Assembly Part 1

Place one of the components with the water pipe into the fountain body at the top.



Step 4. Assembly Part 2

The scimitar pressure well of the well fountain is connected to the top.



Step 5. Connect Tube to Pump

Push tube firmly onto pump outlet. Ensure fully seated.

FINISH SETUP



Step 6. Connect Power / LED

UNPLUGGED + dry hands. Connect pump plug to the rainproof adapter. If LEDs, connect waterproof plug and hand-tighten. Keep adapter/transformer dry and elevated.



Step 7. Fill & Test

Add clean water until pump is fully submerged. Plug in and verify flow. Top off water as needed. Never run dry (check water level daily in hot weather).

PUMP & PLUG SPECIFICATIONS (text version)

Pump (Submersible)

Rated: 120V~ 0.082A 60Hz
Feature: Impedance Protected
Use: Indoor & outdoor use

AC Adaptor / Transformer (Rainproof, Class 2)

Input: 120VAC 60Hz 9W
Output: 12VAC 300mA
UL Listed: E471406
Efficiency Level: VI

Power Plug / Cord

GFCI: Use only with a covered Class A GFCI-protected receptacle.
Orientation: Keep unit vertical/floor-mount.
Keep dry: Do not place plug/connection points in standing water.
Use a drip loop.

TROUBLESHOOTING

- No water flow: add water; check tube; ensure pump submerged.
- Noisy/weak: add water; clean pump intake; remove debris; check kinks.
- Air lock: unplug; add water; gently tilt/shake underwater to release air; plug in again.
- LED off: re-seat waterproof connector; hand-tighten; check outlet.

CARE & STORAGE

- Replace water regularly to reduce algae.
- Clean pump every 2-4 weeks (more often outdoors).
- Freezing weather: unplug, drain, dry, store indoors.
- Mineral buildup: wipe with diluted white vinegar. Do not use bleach or harsh chemicals.