


Assembly Instruction for
DINING TABLE
CXY2366-01

PART LIST		
No.	PART DESC	Q'TY
1	TOP	1
2	LEGS	4

HARDWARE LIST				
NO.		HARDWARE DESC	CODE.	Q'TY
A		ALLEN BOLT (5/16"x57mm)		8
B		SPRING WASHER(5/16")		8
C		FLAT WASHER (5/16"x 22mm)		8
D		ALLEN KEY(M5)		1

NOTES : Do not fully tighten any bolts until last step.

STEP : 1



COMPLETED

