


DINING CHAIR

Assembly Instructions




Thanks for bringing
us into your home


Every thing we make is incredibly
simple to set up, including your new
dining chair. You won't need any
additional tools.

Parts List


A x 1
SEAT



B x 1
FRONT PART



C x 1
BACK PART




Hardware List


HW1 x 8
Split Lock Washer (M6)




HW2 x 8
Flat Washer (M6)



HW3 x 4
Socket Screws 6x1.25x65MM



HW4 x 4
Socket Screws 6x1.25x45MM



HW5 x 2
Dowel (Ø8)




HW6 x 1
Allen Key (M4)




1

Open the box and take out the parts and hardware.




2

Connect the front part (B) to the seat (A) by HW1, HW2, HW4, HW6 as show. Please don't tighten completely.




3

Connect the back part (C) to the step 2 by HW1, HW2, HW3, HW5, HW6 as shown. Please don't tighten completely.



4

Turn the dining chair upright. Make sure all legs are level and fully tighten all the screws.



Place the dining chair in the place where you will use it. We'd love to see it – just tag us and use the hashtag on Instagram!

