

PITTMAN

Queen Fabric Extreme 20" Air Mattress with Built-In Electric Air Pump



PPI-XTREME20 OWNER'S MANUAL

**IT IS HIGHLY RECOMMENDED THAT YOU READ AND FOLLOW
THE INFORMATION CONTAINED IN THIS MANUAL BEFORE
INITIAL SET UP.**

WARNING: THIS PRODUCT IS NOT FLAME RESISTANT. THIS BED CONTAINS PLASTIC. DO NOT PLACE AIR BED NEAR OPEN FLAME OR OTHER SOURCE OF IGNITION.

WARNING: This is not a toy. To avoid risk of fire, burns, injury or shock, it should not be played with or placed where small children can reach it.

- Unplug cord when not in use.
- Pump is an electrical device. Do not use in or around water.
- Do not attempt to disassemble, repair, or service the pump. No serviceable parts are contained inside. Contact Pittman Products International at 15330 Valley View Ave, Suite 2 La Mirada, California 90638 for service or repair.

WARNING:

- This is not a water toy or flotation device. Use as a bed only.
- Not recommended for use by children under three (3) years of age.
- This bed is not intended for infants or persons with limited mobility. They may roll off of the bed and become entrapped between the bed and walls and suffocate.
- Do not use this bed on abrasive surfaces or near pointed, sharp or protruding objects. Bed may puncture. Remove all sharp objects from area the bed will be used in.
- Do not step or jump on bed or use as a trampoline. Standing, jumping or walking on the bed may result in injury and/or damage or puncture the bed.
- Make sure surface is clean of any debris, sharp objects or protrusions or place bed in a safe area before use making sure that there are no sharp edges, steps, drops, or breakable items nearby. Use on flat surfaces only. Bed may tip over on uneven surfaces.

CONTENTS


1. Pittman air mattress with built in AC air pump
2. Repair patch kit
3. Carrying bag

SET UP GUIDE

Your Pittman air bed has a built in air pump as well as a 2 Stage Valve. The 2 Stage Valve is used for optional inflation and deflation.


This Valve is constructed in three parts:

1. Bladder valve with valve lip
2. Middle valve
3. Upper cap



INFLATION

1. Place your bed on a flat surface free of debris, obstructions and sharp objects.
2. Spread the bed out so that it can fill easily. Allowing the bed to "unfold" itself may place an unnecessary strain on the bed and the pump.
3. Make sure Middle Valve (2) and Upper Cap (3) are closed.
4. Turn inflate/deflate valve (B) on the built in pump to the "inflate" position to inflate the bed.
5. Turn inflate/deflate valve to the "off" position once the desired firmness has been achieved.



OPTIONAL INFLATION PROCEDURE

This Pittman air bed comes with a secondary inflate/deflate option (A) for use with portable air pumps as a back up to the installed automatic pump. To use a portable air pump, follow these instructions:

1. The middle valve (2) must be pushed in tightly to the bladder valve (1). The upper cap (3) must be removed from the middle valve in order to inflate.
2. Ensure inflate/deflate valve (B) is in the off position.
3. Insert portable pump into the middle valve (2). (Use proper pump adapter fitting if needed)
3. Remove portable pump and switch off. (Middle valve (2) has a built in stopper that will automatically close when pump is removed stopping any air loss)
4. Replace the upper cap (3).


NOTE: For faster inflate open middle valve (2) and insert pump into bladder valve (1) and fill until almost fully inflated. Once the bed is almost fully inflated, close middle valve (2) then continue filling until desired firmness. Close upper cap (3) when finished.

DEFLATION

1. Turn inflate/deflate valve (B) to the deflate position to deflate bed.
2. Deflate until bed is fully deflated. For faster deflation, you may open the middle valve (2).
3. Turn inflate/deflate valve to the off position to turn pump off.
4. Fold bed according to Folding Instructions below and place into carrying bag and store until next use.

FOLDING INSTRUCTIONS

1. Upon complete deflation, lay bed on flat surface with sleeping surface facing upwards and fold according to the steps below.



**actual bag may vary*

CARE AND MAINTENANCE

1. Inspect your bed before each use.
2. Keep your bed away from any sharp or protruding objects. Large cuts, tears or snags may not be repairable and will not be covered by your warranty.
3. A repair patch kit has been included in case of incidental damage to your bed. Please follow repair instructions carefully.
4. When not in use store bed in a clean, dry place out of extreme temperatures.

CLEANING

DO NOT SUBMERGE BED IN WATER! For spot cleaning, use a clean damp cloth to wipe the surface of the bed. Apply a clear liquid dish detergent without dye if necessary. Wet stained area thoroughly; gently massage stained area with detergent. Blot the area to remove staining substance. Rinse thoroughly and blot dry. Allow your bed to air dry completely after cleaning and before storing.

ADDITIONAL INFORMATION

IN CASE OF AIR LEAKAGE

Please check the following if there is an air leak.

1. Is the inflate/deflate valve on built in pump turned to inflate position?
2. Is the secondary inflate/deflate valve cap closed?

A repair patch kit has been included for minor repairs.

REPAIRING AN AIR LEAK

1. Wipe bed with mild soap water over area to find possible air leak. DO NOT SUBMERGE MATTRESS IN WATER! If there is a leak bubbles will form around leakage area.
2. Follow cleaning instructions for leak area.
3. Use included patch kit to cut a suitable sized patch for leak. Make sure to round the edges of repair patch to avoid peeling.
4. Apply glue to patch area and around leakage area.
5. Press patch firmly over the puncture area.
6. Wait one hour before inflating.

Please Note:

Stretching is a natural occurrence of new vinyl. During the first days of use, this air bed may become soft and require additional inflation to maintain desired firmness.



WARRANTY DISCLAIMER

Pittman Air Beds are warranted against defects in material and workmanship for a period of One Year from the date of purchase. Problems covered by the warranty include failure of the pump, seams or the valve. Punctures or wear to the bed due to use or abuse are not covered.

It is normal for an airbed that has been inflated for extended periods to require the addition of air after a few days. Air will be lost from the bed through the material over time. Also, cooling of the air around the bed will cause the air inside the bed to contract, and the bed will be softer and may need refilling. To receive a replacement air bed under Pittman Products International's One Year Warranty, you will need to:

- All returns must have a Returned Goods Authorization number (RGA). Every package must be clearly marked with the RGA number. RGA numbers are good for 30 days from the date of issuance. Products returned without viewable RGA numbers will be refused. No returns on special order, clearance or discounted items. Returned products is subject to a 20% Re-Box/Restocking fee. Products must be properly packed to prevent shipping damage. All returned product must be shipped pre-paid.
- Send entire product to Pittman Products International with a letter stating:
 - The nature of the problem with the bed and the model number.
 - Your name, return shipping address and a daytime phone number.
- Send us a copy of the original sales receipt.

The purchase date on the receipt must be within One Year of the date you ship the bed to us.

Please ship the bed, letter and copy of receipt, and UPC Symbol, via courier (e.g. UPS, FedEx Ground) or Insured Post, to:

Pittman Products International
Attn: Returns
15330 Valley View Ave, Suite 2
La Mirada, California 90638

Pittman Products International is not responsible for returned shipments lost in transit. You are encouraged to use a shipment system that offers you a tracking number. Please allow 6 to 8 weeks for replacement. Customer is responsible for all return shipping costs.

EXCEPT FOR THE EXPRESS LIMITED WARRANTY SET FORTH ABOVE, PITTMAN PRODUCTS INTERNATIONAL MAKES NO EXPRESS OR IMPLIED WARRANTIES IN THIS AGREEMENT OR OTHERWISE. TO THE FULLEST EXTENT PERMITTED BY LAW, PITTMAN PRODUCTS INTERNATIONAL DISCLAIMS ALL WARRANTIES, WRITTEN, EXPRESSED OR IMPLIED, INCLUDING ALL WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE. PITTMAN PRODUCTS INTERNATIONAL EXPRESSLY DISCLAIMS ANY AND ALL LIABILITY TO PURCHASER FOR ANY CONSEQUENTIAL DAMAGES, DAMAGES FOR LOSS OF USE, LOSS OF PROFITS, PROPERTY DAMAGE, OR ANY OTHER INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES ARISING OUT OF THIS AGREEMENT OR THEIR OPERATION, FUNCTION OR CHARACTERISTICS OF THE PRODUCTS PURCHASED HEREUNDER. IT IS EXPRESSLY UNDERSTOOD THAT THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND EXCLUSIVE REMEDY OF PURCHASER. NOTWITHSTANDING THE TERMS OF ANY LIMITED WARRANTY, AND/OR IN THE EVENT ANY LIMITED WARRANTY PROVIDED TO THE PURCHASER FAILS OF ITS ESSENTIAL PURPOSE, IN NO EVENT WILL PITTMAN PRODUCTS INTERNATIONAL ENTIRE LIABILITY TO PURCHASE EXCEED THE PURCHASE PRICE ACTUALLY PAID BY PURCHASER FOR THE PRODUCTS HEREUNDER, OR ANY DEFECTIVE PORTION THEREOF, WHICHEVER IS THE LESSER AMOUNT.

Pittman Products International neither assumes nor authorizes any representative or other person to assume any obligation or liability other than those expressly set forth herein.

YOUR RIGHT UNDER STATE LAW: This warranty gives you specific rights and you may also have other rights, which vary from state to state.

© 2016 Pittman Products International
All rights reserved.

Made in China.

Our Customer Service Department is available Monday - Friday, 9 AM to 5 PM Pacific Standard Time, to answer any questions you may have about your new Pittman air bed product please call us toll free at 1 (800) 981-2339. U.S.A.

15330 Valley View Ave, Suite 2
La Mirada, California 90638
1 (800) 981-2339
www.pittmanproducts.com

OTHER GREAT PRODUCTS FROM PITTMAN OUTDOORS

www.pittmanoutdoors.com

The Original
AirBedz[®]
Truck Bed Air Mattress



Rear seat air mattress

