


INSTRUCTION

3+



NOTE : Please read instructions before assembly
If incorrect assembly, could reasonably result in the creation of a hazard



WARNING:

Product must be assembled by an adult.
Keep small parts necessary for assembly
out of children's reach.



WARNING:


CHOKING HAZARD-Small parts.
Not for children under 3 years




1 x1pcs




2 x1pcs




3 x2pcs




4 x3pcs




5 x1pcs



6 x1pcs



7 x1pcs



8 x2pcs



9 x12pcs



10 x6pcs




11 x16pcs



12 x16pcs




13 x1pcs




TOOL REQUIRED
(NOT INCLUDED)

1



	
9 x2	10 x6


2



Note:The white plastic nut must be pressed all the way down.

	
9 x2	11 x4


3



NOTE:SCREW THE PINS INTO THEIR CORRESPONDING HOLES ONLY ASDEEP AS THEIR THREADS FOR STEEPS 3,4,5AND8 . INSERT THE CAMSINTOtheir HOLES. SECURE THECAM AROUND THE HEAD OF THEPIN BYTURNING CLOCKWISEUNTIL IT IS TIGHT.


12 x4


4



11 x4

12 x4

5



9


9

12 x2

9 x2

11 x2


6



8


8

7



9 x6

8



12 x6



11 x6

9

