封底


封面

14cm

21cm

PRODUCT ASSEMBLY

2 Connect all the corresponding plugs.
Spread out the branches and arrange them to your preference.
Insert the bottom plug into a wall outlet to turn the lights on.



CLEANING & STORAGE

- Store this tree in a cool and dry place away from heat and moisture.
- Before putting this tree in storage, do the following:
  - Completely remove all decorations.
  - Clean the tree with a slightly damped cloth and let it dry naturally.
  - Raise all branches to original upright position; make sure not to damage any branches in the process.

MADE IN CHINA




Artificial Holiday Christmas Tree

ⓘ NOTICE

Please retain these instructions for future reference.


- Firmly secure all screws before use.
- Product is intended for indoor use only.
- Do not place this tree in a wet location.
- This seasonal product is not intended for permanent installation or use.
- Do not use or store this item in the proximity of open flame, flammable/combustible chemicals, or other strong heat sources.
- If any parts are missing, broken, damaged, or worn, stop using this item until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with the manufacturer's instructions as this could void the product warranty.

HARDWARE





PARTS



NOTE: Wires may come wrapped around frame pieces. Locate and unwrap wires before assembly.



Please remove the caps on the end of the poles before assembly.

PRODUCT ASSEMBLY

1 Assemble the tree.

NOTE: Bottom section is wider than the top section.
Make sure sections are arranged in the correct order.

