





Instruction Manual

Thank you for shopping with us!








If any parts is missing, broken upon receipt or you need any help from us. For the FASTEST solutions, please FIRSTLY CONTACT US at our after-sales

Accessories list

Note: All the parts or hardware marked with*are tucked under seat frame


A  Left seat frame	B  Right seat frame	C  Coffee Table Board(1)	D  Armrest bag(2)
--	---	---	---

Hardware list

E *  M5x95x35Wrench(1)	F *  16mmGasket (4)	G *  6x22Screw(4)	H *  70x25x3 Foot plate(2)
I *  Middle foot of sofa(4)	J *  Sofa foot (2)	K *  8*50Screw(6)	


Step 1:

Get all the hidden parts out of A and B




STEP 2:

Fix the metal plates to make the seat frames connected follow by installing the legs




STEP 3:

Lift up the backrest and insert the coffee table. Fix with screws and stick on Velcro




STEP 4:

Put the armrest bag on the sofa




STEP 5:

Put down the coffee table and the assembly is finished




STEP 6:

The backrest is adjustable for three angles




Angle One
105°



Angle Two
135°

Tip:

Pull the backrest forward till you hear the snap sound and push it backwards slowly to the angle you want.



Angle Three
180°