

Assembly&InstructionManual

3 SEAT SWING

Swing Installation Guide



Save this manual for future reference

INTRODUCTION

Thank you for purchasing Patio Swing ! We hope you will find joy in our products for many years to come.

To ensure your personal safety during installation and to get the most out of your investment, please read this entire manual before beginning the installation process. If you feel that this process is too difficult to do on your own, we advise that you seek assistance from a local building or home improvement contractor.

We believe that installation can be a simple, streamlined process if you follow the instructions in this manual. Please contact our customer support line for help any step of the way. If you need assistance with assembly, have missing or defective parts, or any other issues, please email us

CARE AND MAINTENANCE

FRAMES

Cleaning- Use mild soap and warm water. Do not use abrasive materials, cleansers or bleach products. Rinse with clean water and dry thoroughly.

Maintenance- Periodically clean and dry thoroughly. Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove foot caps and tilt the frames, if necessary, to remove all water. This is critical. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to the frame tubing. Such damage is not covered under warranty. Always clean, drain and dry thoroughly before storing for the winter. For best results, always store or cover your furniture when not in use. We recommend commercially available outdoor furniture covers.

****** When cleaning or moving large or heavy items, always have two people work together. Never drag furniture.

FABRICS (CUSHIONS/SLINGS)

Cleaning - Maintenance Wipe minor spills immediately. Clean with mild soap, warm clean water and a soft cloth. Do not use abrasive materials and cleansers. Although fabric has been treated to resist stains, occasional use of commercially available fabric cleaners may be necessary. Follow manufacturer's instructions.

Maintenance- The best way to maintain the beauty of cushions and slings is to store them in a dry area and out of the elements when not in use, or cover with commercially available outdoor furniture covers.

WARNING





THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY, NOT FOR COMMERCIAL USE.







Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings. Keep children away during assembly. This item contains small parts which can be swallowed by children. Children should always be under direct adult supervision while using the product. Retain the assembly instructions for future reference.

This swing must be installed on level ground.





- Assemble 6 feet or more away from obstruction such as fence, garage, house, hot grills, overhanging branches, laundry wires and electrical wires...etc.
- Tighten all nuts, bolts and components during assembly and periodically during usage, fail to do so will be on your own risk
- Lubricate all moving parts during usage season.
- It is advisable to wear goggles during assembly.
- It is recommended that two or more person assemble this swing.
- Use with proper cautions especially accompany with young children. Gentle swing action is recommended for both adult and young children. Younger children should not be left alone without adult accompany on the swing.
- Maximum weight capacity **300** pound.
- Make sure to have help when removing seat from the frame or when moving the swing.
- No machine wash or dry clean for all the fabric materials, use hand wash with care only.


PARTS LIST

Parts	Desc	Qty
A		1
B		1
C		2
D		1
E		1
F		2
G		1
H		1
I		1
J		1
K		1
L		4
M		2
N		2


Parts	Desc	Qty
O		1
P		1
Q		3
R		3
S		2
T		2
U		1
V		2
W		1
X		1
Y		1
1	 M8x100	4
2	 M8x80	4
3	 M8x75	2

PARTS LIST


Parts	Desc	Qty
4	 M8x65	2
5	 M8x53	2
6	 M8x40	2
7	 M8x32	1
8	 M8x20	2
9	 M6x95	4

Parts	Desc	Qty
10	 M6x45	8
11	 M6x35	9
12	 M8	7
13		7
14	 M6	4
15		4


1




2




3




4




5




6




7




8




9



10



11



12

