


Owner Manual





Thank you for shopping with us!

We encourage you to take a few minutes to go through this booklet. It contains important information on installation and care tips to keep your furniture looking as good as new.


Hardware

NO.	Draw	QTY	NO.	Draw	QTY
A	 Screws Ø4x14mm	60	J	 Hinges(Internal hiding)	4
B	 Two-in-one connector	35	K	 Plastic side panel	1
C	 Two-in-one connector	35	L	 Track	1
D	 Wood plug	4	M	 Screws Ø4x20mm	4
E	 Plastic anchor(Ø10mm)	2	N	 Anti-collision gasket	8
F	 Screws for fix on the wall	2	O	 Screwdriver	1
G	 Bracket (53x70x44mm)	2			
H	 Bracket (19x19x35mm)	1			
I	 Screws Ø4x25mm	1			


Recommended tools



Dimensions




Components



Step 1

Note: Follow the holes positions exactly.



x1

L

($\varnothing 4 \times 14\text{mm}$)



x3


A



Tool

Step 2

Note: Follow the holes positions exactly.



x1

L

($\varnothing 4 \times 14\text{mm}$)









x3

A




Tool

Step 3






Notes: Screw installation depth as shown

Attention: Cam lock arrow point to the steel rod.




	x5
B	
	x5
C	
O	

Step 4




	x2
B	
	x2
C	
O	

Step 5




	x2
B	
	x2
C	
	
O	

Step 6



	x1
B	
	x1
C	
	
O	


Step 7



	x9
B	
	x9
C	
	x2
D	
O	

Note: The D parts are used for these two holes.


Step 8



	x9
B	
	x9
C	
	x2
D	
O	

Note: The D parts are used for these two holes.

Step 9



 x2

B

 x2

C

 x1

H

(Ø4 x 25mm)

 x1

I

(Ø4 x 14mm)

 x4


A



O


Tool

Step 10



(Ø4 x 14mm)

 x12




A

 x2

G


Tool

Step 11



 x2

B

 x2

C

 x1

K

($\varnothing 4 \times 14\text{mm}$)
 x10

A




O




Tool


Step 12



Note: Remove the cover according to the diagram and align it with the hole to lock the self powered screws M.



	x3
B	
	x3
C	
(Ø4 x 20mm)	
	x4
M	
O	
Tool	



Step 13



(Ø4 x 14mm)




A




Tool




Note: The bottom hole under the rail is stuck on this hole in the plastic side plate and locks the screw at the bottom.




Note: The bottom of the rail is fixed with screw A. The rails adjust their height 3mm.



Note: stuck the rear holes.




Step 14



	x4
J	
(Ø4 x 14mm)	
	x24
A	
	x8
N	
	
Tool	


You can adjust the doors by tightening or loosening the screws on the hinge.




Step 15




+



Step 16



a



Step 17






E





Tool




Step 18



Step 19




Finished




The specific basin type is subject to your purchase order.

Dimensions




Top View



Front View

Recommended installation height



Side View

Floor

CARE CLEANING AND MAINTENANCE

1. Dust regularly with a soft , dry cloth.
2. Avoid the use of all chemicals household cleaners, abrasives, or cleaners that contain lemon, vinegar, or other acids that may damage the finish.
3. Excessive exposure to sunlight and extreme changes in temperature and moisture can damage wood furniture.
4. The sink is fragile, please pay attention to maintaining its appearance.
5. Do not place hot appliances, such as curling irons and hot hair dryers directly on the countertop. Wipe spills immediately.