
## 3 LIGHT KITCHEN ISLAND CHANDELIER


## ASSEMBLY INSTRUCTIONS

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



## 3 LIGHT KITCHEN ISLAND CHANDELIER

REMOVE ALL PARTS FROM PACKAGE, BE CAREFUL NOT TO DAMAGE ANY COMPONENTS.



- 1. Measure area and determine desired hanging height.
- 2. Adjust the length of the cord by loosening the screw on the stem of the canopy with the provided screwdriver [A]. Re-tighten screw after desired cord length is achieved.
- Feed the support wires into the canopy (To lengthen support wires compress neck [B] into canopy and pull wire out).
- **4.** Detach mounting plate [C] from canopy [D] by removing canopy screws [E].
- **5.** Mounting plate [C] will attach to ceiling junction box.
- 6. Install light to ceiling. We recommend installation by a qualified electrical professional. Canopy screws [E] are used to tighten light to ceiling.
- Install the Glass shades [F] onto socket [G] and tighten by using shade screws [H]. Install bulbs 60W max (Not included).

