











CARE AND MAINTENCE

Wipe clean with a soft, dry cloth. The seat board can be cleaned with a mild cleaner. Test the cleaning method on a hidden area before using them over the entire area.


NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finished product during assembly.
- * This item may require periodic tightening.
- * Do not tighten bolts until completely assembled.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat Frame		1 X
B1	Leg		1 X
B2	Leg		1 X
B3	Leg		1 X
B4	Leg		1 X
B5	Leg		1 X
B6	Leg		1 X
C	Support Leg		3 X
H1	Allen Bolt	 1/4"*1-1/2"	36 X
H2	Allen Key	 M4	1 X

Product Dimensions:86"W*40-1/2"D*31"H



Weight capacity:750lbs
WARNING:DO NOT STAND ON THE SOFA


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 20 minutes.

Tools Required for Assembly (included): Allen Key.


1



Step 1

Attach 6*legs (B1/B2/B3/B4/B5/B6) and 3*Support legs (C) in the corresponding position on the bottom of seat (A) by using Allen key (H2) to lock with 36*Allen bolts (H1) as picture.

2



Step 2

Assembly is completed.