
OWNER MANUAL



1. Thank you for choosing ***our products.***

2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expectations or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solution. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solution or answer any questions you may have.

Recommendations Before Beginning Assembly

 • Read instructions, cover to cover

 • Have 2-4 adults on hand for assembly depending on product size

 • Do not assemble directly on flooring or carpet

 • Assemble on a clean non-marring surface (example: packing foam)

 • Save all packaging until finished

3. Assembly Notice:

- If you encounter any problems during assembly and find that you cannot continue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the parts out. One by one, Place the parts out neatly in front of you, then refer to the instructions to ensure no parts are missing. If any pieces are found missing, please carefully look in the box first, as the hardware packaging might have torn making the

hardware spill in the box.

- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- IMPORTANT: When setting up your product, DO NOT INSTALL THE SCREWS ALL THE WAY IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist the screw halfway. Twist all the screws in halfway to ensure the holes will match up properly and the product is level on the ground. When everything seems fitted, then tighten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.

Care & Maintenance


Do not put hot items directly on furniture surface


Do not clean furniture with harsh cleansers or polish


Do not place furniture under direct sunlight


Do not place furniture near heating or cooling vents


Do not write on furniture without a padded barrier to protect the surface


Do not place furniture outside. For indoor use only


Not for commercial use. For residential use only


Stains may be removed with mild soap solution and damp cloth



Children should not climb or jump on the furniture



Dust and pick-up spills using a clean, non-colored, lint-free cloth


Caution










● This product contains small components. Please ensure that they are kept away from children.

● Do not use power tools to assemble your furniture. Power tools may strip or damage the










1
9
8
7
4
9
7
6
5
8
6
3
2
10
10
10
10
10
12
11
14
13
15
16
15
16

 Ø6x35mm	 Ø15x10mm	 Ø5x60mm	 Ø8x45mm	
AX6	BX6	CX4	DX5	EX1
 Ø3x14mm				
FX12	GX2	HX8	KX4	SX4
 Ø4x14mm		 Ø6x25mm	 X2 N1 N2 N3 N4 N5	
JX48	LX8	MX8	NX1	
	 Ø6x30mm		 Ø5x45mm	
OX4	PX 12	QX1	RX 2	


STEP 1







 Ø5x45mm	 Ø 6x30mm	 Ø8x45mm		
RX2	PX2	DX1	EX1	QX1


STEP 2


4
P
P
5
C
3
2
C
Q
P
P
C
C



Ø5x60mm
CX4
Ø 6x30mm
PX4


STEP 3


E
D
D
D
10
2
D
10
D
10
10



Ø8x45mm
DX4

STEP 4



9
9
7
8
9
8
7
7
8
Px6
4
5
3


Ø 6x30mm
PX6


STEP 5




A
A
1
A
A
A
F F
G
F F
G
E
F
F
G



Ø6x35mm
AX6
Ø3x14mm
FX4
GX2

STEP 6



STEP 7









Ø15x10mm

BX6


STEP 8





 Ø4x14mm		Ø6x25mm
J X8	KX4	MX4

STEP 9

Tip: Corresponding hinge letters to wooden board letters









NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.

 Ø4 x14mm
J X16


STEP 10





	 Ø4x14 mm	 Ø6x25mm
SX4	JX8	MX4

STEP 11

Tip: Corresponding hinge letters to wooden board letters








NOTE: If the doors are uneven or there is a gap in the middle, loosen or tighten the screw on the door hinge until they are sitting flush.


 Ø4x14mm
J X16


STEP 12




	
HX8	OX4


STEP 13



	 Ø3x14mm
LX8	FX8

STEP 14





STEP 15

