






Saddle Stool Chair

OWNER'S MANUAL





Parts

Code	Image	Parts Name	Qty(Pcs)	Code	Image	Parts Name	Qty(Pcs)
1		Backrest	1	2		Seat	1
3		Mechanism	1	4		Gaslift	1
5		Leg	1	6		Caster	5
7		Plastic Cover	1	8		Back Connecting Rod	1
9		Hex Screw M6*20	6				


Tools

Code	Image	Tools Name	Qty(Pcs)
10	 M6	Allen Key	1

Installation Diagram


Step One:

Insert 5pcs of Caster ⑥ into the leg⑤




Step Two:

Put gaslift④ into the leg⑤




Step Three:

Attach mechanism③ on the seat② by using 4pcs of screw⑨



Step Four:


Turn the stool over and place it on the gaslift



Step Five:



Attach the Back Connecting Rod on the back ①
put the plastic cover on the metal
then tighten by screw ⑨

⑨ x 2




Step Six:

Insert the backrest into the mechanism




Instruction for use

Push the handle upwards and the chair can be raised or lowered



Push the handle upwards to tilt the backrest to any angle.
Push the handle downwards to fix the backrest in the position you need.



Rotate the knob counterclockwise to adjust the backrest height.
Rotate clockwise to lock the backrest at the height you need.

