




[L SHAPED DESK]



USER MANUAL



Contents


TOPIC	PAGE
01	
SAFETY INSTRUCTIONS	01-01
1-1	Thank You For Choosing Our Product 01
1-2	Precautions 01
02	
INSTALLING MODULES	02-59
2-1	Disassembly Diagram 02
2-2	Parts List 03-05
2-3	Assembly Instructions 06-59
03	
CUSTOMER SERVICE	60
3-1	30-Day Return Policy 60
3-2	1-Year Warranty 60
3-3	Quick Response Within 24 Hours 60
04	
PROBLEMS YOU MAY ENCOUNTER	61
4-1	Problems You May Encounter 61

Safety Instructions

Thank You For Choosing Our Product

Before assembly, please read this USER MANUAL first, and check according to Parts List to make sure all parts are included. Feel free to contact us if you have any concerns or questions about your product, we are always ready to help. Your satisfaction is our first priority!


Precautions




- Avoid long-term direct sunlight exposure.



- Keep away from sharp objects.




- Keep away from heat.



- Keep infants/children away from assembly parts to avoid choking and suffocation.




- Keep away from corrosive substances.





- Pay attention to avoid over-tightening fasteners, or they may induce cracking within the board.





















Disassembly Diagram



Parts List



For ease and safety, we recommend two people for assembly.


















A x1 	B x1 	C x1 	D x1 
E x1 	F x1 	G x2 	H x1 
I x1 	J x1 	K x1 	L x1 
M x1 	N x1 	O x1 	P x1 
Q x1 	R x1 	S x1 	T x1 












Parts List

For ease and safety, we recommend two people for assembly.



U x1 	V x2 	W x1 	X x1 
Y x1 	Z x1 	a x1 	b x1 
c x1 	d x1 	e x2 	f x1 
g x2 	h x2 	i x1 	j x1 
k x2  Left+Right			

Parts List


① x4  M6x10 1 Spare	② x5  M6x20 1 Spare	③ x33  M6x28 3 Spares	④ x5  M4x25 1 Spare
⑥ x25  ST4x12 3 Spares	⑦ x5  ST3.5x16 1 Spare	⑧ x30  M6x48 3 Spares	⑨ x14  Φ12x10 2 Spares
⑩ x14  M6x40 2 Spares	⑪ x9  M6x30 1 Spare	⑫ x5  1 Spare	⑬ x2 
⑭ x1 	⑮ x5  1 Spare	⑯ x2  1 Spare	⑰ x1 

Assembly Instructions




Attention: The shelves can be installed on either side, you can choose one instruction as you prefer.

R1-R28: Drawers on the right side.




L1-L28: Drawers on the left side.



Assembly Instructions

R-1

Use screws ③ to install a, W and c. Please note that one end of a must be installed into the upper hole of W which is closer to the edge.





③ x6 	⑫ x4 	⑮ x1 						
W x1 	X x1 	a x1 	c x1 	d x1 				


Assembly Instructions

R-2

Please make sure k-CL and the holes on J are perfectly aligned, then secure using Screw ⑥.

LEFT





J x1		k-CL x2		⑥ x6		17 x1	
----------------	---	-------------------	---	----------------	---	-----------------	---


Assembly Instructions

R-3


Please make sure k-CR and the holes on K are perfectly aligned, then secure using Screw ⑥.


RIGHT




K x1		k-CR x2		⑥ x6		17 x1	
----------------	---	-------------------	---	----------------	---	-----------------	---

R-4




8		16	
x7		x1	

C		D		J		X	
x1		x1		x1		x1	

R-5


3	
x2	
16	
x1	
b	
x1	



Assembly Instructions

R-6

Insert part ⑪ fully into the holes on both sides of H, L, I, and F until it's securely seated.




⑪		F		H		I		L	
x8		x1		x1		x1		x1	

Assembly Instructions

R-7




Use screw ⑧ to attach one side of H, L, I, F which are fully inserted ⑪ to J.

Note: The hole on L must face downward.






⑧ x4		⑩ x1	
F x1		H x1	
I x1		L x1	

R-8






R-9




R-10

G

x1




R-11



M		8		16	
x1		x4		x1	

Assembly Instructions


R-12 Use screw ① and Screw ③ to attach Y and Z to W. Please install W according to the hole orientation on Z indicated by arrows.



W x1	Y x1	Z x1	① x1	③ x3	①6 x1
---------	---------	---------	---------	---------	----------

Assembly Instructions



R-13 Insert Screw ⑩ into R, N and tighten completely.




N		R		⑩		⑰	
x1		x1		x8		x1	

Assembly Instructions


R-14







Insert Cam Bolt



Press The Cam Lock





Tighten It Clockwise





P x1		Q x1		T x1		U x1		9 x8		16 x1	
----------------	--	----------------	--	----------------	--	----------------	--	----------------	--	-----------------	--

Assembly Instructions





R-15



R-16






R-17




4		13		17	
x4		x2		x1	

Assembly Instructions



- R-18** Align holes on DL, DR with the corresponding holes on drawer base and secure using Screw ⑥.



⑥		⑬		k-DL		k-DR	
x8		x1		x2		x2	







Assembly Instructions

R-19 h can be installed at either Position 1 or 2 according to your preference.








Assembly Instructions

R-20







R-21





Assembly Instructions

R-22 Connect B to the pre-assembled unit using Screw ⑩ and tighten completely.


B x1	
3 x3	
10 x4	
16 x1	
17 x1	




R-23




Insert Cam Bolt




Press The Cam Lock





Tighten It Clockwise




9		17	
x4		x1	



R-24

A	
x1	
3	
x7	
16	
x1	



R-25




g		j		2		6		16		17	
x2	/	x1		x4		x2		x1		x1	

Assembly Instructions

R-26

Use screw ① to connect f to E. Use Screw ③ to connect e to E.
Note: Using incorrect screws may cause the board to crack.

①	
x2	
③	
x4	
16	
x1	
E	
x1	
e	
x2	
f	
x1	




R-27

Use 3M tape to attach i to E.




Note: First light up the light strip to confirm its front or back side and then apply 3M tape to prevent sticking to the front side which will affect the lighting.

i	
x1	



Assembly Instructions


R-28 Use sticker ⑮ to cover the reserved mounting holes for reversible assembly.



Assembly Instructions

L-1

Use screws ③ to install a, W and c. Please note that one end of a must be installed into the upper hole of W which is closer to the edge.



③ x6		12 x4		16 x1	
---------	--	----------	--	----------	--



W x1		X x1		a x1		c x1		d x1	
---------	--	---------	--	---------	--	---------	--	---------	--


Assembly Instructions

L-2

Please make sure k-CL and the holes on J are perfectly aligned, then secure using Screw ⑥.

LEFT





J x1		k-CL x2		⑥ x6		17 x1	
----------------	---	-------------------	---	----------------	---	-----------------	---


Assembly Instructions

L-3


Please make sure k -CR and the holes on K are perfectly aligned, then secure using Screw ⑥.

RIGHT



K x1		k-CR x2		⑥ x6		17 x1	
----------------	---	-------------------	---	----------------	---	-----------------	---

L-4




8 x7		16 x1	
C x1		D x1	

K x1		X x1	
---------	--	---------	--

Assembly Instructions

L-5


③ x2	
⑬ x1	
b x1	



Assembly Instructions

L-6

Insert part ⑪ fully into the holes on both sides of H, L, I, and F until it's securely seated.




⑪ x8		F x1		H x1		I x1		L x1	
---------	--	---------	--	---------	--	---------	--	---------	--

Assembly Instructions

L-7




Use screw ⑧ to attach one side of H, L, I, F which are fully inserted ⑪ to J.

Note: The hole on L must face downward.



⑧ x4		⑪ x1	
F x1		H x1	
I x1		L x1	


L-8




G
x1



L-9







8		16		J	
x4		x1		x1	


L-10




G

x1




L-11



M x1		8 x4		16 x1	
---------	---	---------	---	----------	---

Assembly Instructions


L-12 Use screw ① and Screw ③ to attach Y and Z to W. Please install W according to the hole orientation on Z indicated by arrows.




W x1	Y x1	Z x1	① x1	③ x3	①6 x1
---------	---------	---------	---------	---------	----------

Assembly Instructions



L-13 Insert Screw ⑩ into R, N and tighten completely.




N		R		⑩		⑰	
x1		x1		x8		x1	

Assembly Instructions


L-14







Align Two Boards
Insert Cam Bolt



Align Arrow with Cam Bolt
Press The Cam Lock





Tighten It Clockwise





P x1		Q x1		T x1		U x1		9 x8		16 x1	
----------------	--	----------------	--	----------------	--	----------------	--	----------------	--	-----------------	--

Assembly Instructions





L-15



L-16






L-17




4		13		17	
x4		x2		x1	

Assembly Instructions



- L-18** Align holes on DL, DR with the corresponding holes on drawer base and secure using Screw ⑥.









⑥		⑬		k-DL		k-DR	
x8		x1		x2		x2	

Assembly Instructions






L-19 h can be installed at either Position 1 or 2 according to your preference.



L-20







L-21



Assembly Instructions



L-22 Connect B to the pre-assembled unit using Screw ⑩ and tighten completely.

B x1	
3 x3	
10 x4	
16 x1	
17 x1	




Assembly Instructions


L-23




Insert Cam Bolt




Press The Cam Lock




Tighten It Clockwise






L-24

A	
x1	
3	
x7	
16	
x1	



L-25




g		j		2		6		16		17	
x2	/	x1		x4		x2		x1		x1	

Assembly Instructions

L-26

Use screw ① to connect f to E. Use Screw ③ to connect e to E.
Note: Using incorrect screws may cause the board to crack.

①	
x2	
③	
x4	
16	
x1	
E	
x1	
e	
x2	
f	
x1	




L-27

Use 3M tape to attach i to E.




Note: First light up the light strip to confirm its front or back side and then apply 3M tape to prevent sticking to the front side which will affect the lighting.

i	
x1	



Assembly Instructions

L-28 Use sticker ⑮ to cover the reserved mounting holes for reversible assembly.



Assembly Instructions



Static Color Button




Dynamic Mode Button



S / B

Speed & Brightness
and Power Button



STATIC COLOR BUTTON

Press this button once to switch to the static color mode, and then each pressing can change the color.

DYNAMIC MODE BUTTON

Press this button once to switch to the dynamic mode effect, and then each pressing can change the dynamic mode.

Press this button for more than 3s to switch to the demo mode; In the demo mode, the strip will automatically cycle through various dynamic modes.

SPEED & BRIGHTNESS AND POWER BUTTON

A. In the static mode, press this button to adjust the brightness of the light bar; each press can switch to a brightness level.

B. In the dynamic mode, press this button to adjust the dynamic mode speed; each press can switch to a speed level.

C. Press and hold this button to shut it down when the strip is on. Press this button to turn it on when the strip is off.

The product has a power-off memory function; the strip can restore the color, brightness, and mode in the next power-on.



30 DAY Return Policy

If you're not completely satisfied with your purchase, please return the merchandise via our Official Customer Support. Unused merchandise can be refunded or exchanged within 30 days of purchase.



1-Year Warranty

We guarantee your product is free from defects in product material and workmanship for one (1) year starting from the date of purchase during normal use of household conditions. If your appliance fails to operate properly within our warranty period, we will arrange a new one. Replacement is free and all shipping costs are covered.



Quick Response within 24 Hours

If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
Whole Product	Parts are missing, defective or having wrong parts in package.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Having issue(s) while reading the instruction or completing the assembly.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	Encountering non-human caused damage during use.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Furniture Surface	Surface is broken, scratched or lack of some screw holes.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The screw holes that on the board and the frame don't line up.	1. Tighten the screws only 70% of the way. Do not fully tighten the screws until all parts are aligned. 2. Adjust the board and frame until the holes align, then fully tighten all screws.
	Surface is uneven or not tight that has gaps after being assembled.	1. Loosen the screws in the uneven or gap positions; adjust until the surface is flat and tight, and then tighten the screws. 2. If your problem still can't be solved, please feel free to contact us.
Structure Frame	Components are bent, broken, chipped, rusted, or damaged.	Contact us via our after-sales phone or email. We will respond within 24 hours.
	The furniture is unstable after being assembled.	1. Check if all screws are fully tightened. 2. Read through the manual and check if any parts are installed incorrectly or missing. 3. If the problem persists, please contact us.
	Encountering non-human caused damage during use.	If the product is damaged due to non-human causes, please keep the product and send us photos of it. We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.

We are committed to providing our customers with premium
quality products and convenient customer service.

MADE IN CHINA