
ASSEMBLY INSTRUCTIONS
CABINET




WARNING


CSU

This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware. Compare with the parts list to be sure all parts are present.
"DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED"

* Use of power tool to assemble this product will invalidate any claim and damage this product making unsafe!!!
* Please assemble on a clean soft surface to avoid damage.





Tools Required



(Not Included)



(Not Included)

IMPORTANT:
PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

Before Installation

Important - Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

. We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.


. Please do not over tighten screws or bolts until the assembly is completed.

. Keep children and animal away from the work area, small parts could choke if swallowed.


. Please put all parts on a non-abrasive floor before assembly,and follow the assembly steps to assemble your newly purchased product correctly and efficently.

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.

Cam Lock Assembly Instructions











Detail View - CABINET







Identifying the Hardware - identify the hardware using the illustrations below.














Part List

1  Top Panel - 1pc	2  Side Panel Left - 1pc
3  Side Panel Right - 1pc	4  Mid Panel - 1pc
5  Bottom Panel - 1pc	6  Side Panel Left - 1pc
7  Side Panel Right - 1pc	8  Mid Panel - 1pc
9  Drawer Panel - 1pc	













Part List

10  Top Panel - 1pc	11  Mid Panel - 1pc
12  Back Frame - 1pc	13  Front Top Bar - 1pc


Part List


14  Back Panel Top - 1pc	15  Door Cabinet Top - 2pcs
16  Door Cabinet Bottom - 2pcs	17  Mid Bar Rear - 1pc
18  Front Bottom Bar - 1pc	19  Back Bottom Bar - 1pc
20  Drawer Face - 1pc	21  Drawer Back Panel - 1pc
22  Drawer Side Panel (L) - 1pc	23  Drawer Side Panel (R) - 1pc
24  Bottom Drawer Panel - 1pc	25  Glass Shelf Panel - 1pc
26  Back Panel Bottom - 1pc	


Hardware List

A  ø13x1/4"x28mm	B  ø13x1/4"x50mm	C  ø1/4"x16x1mm
Hex-Head bolts(16pcs+1)	Hex-Head bolts(2pcs+1)	Washer(18pcs+1)
D  1/4"Xø10x13mm	E  ø6x35mm	F  ø14.5x12mm
Horizontal-Hole bolts(2pcs+1)	Three in one bolts (27pcs+1)	Three in one lock (27pcs+1)
G  ø8xø4x32mm	H 	I 
Round head screw (8pcs+1)	Handle (2pcs)	Handle (4pcs)
J  ø5/32"x28mm	K 	L 
Handle screw (8pcs+1)	Damping hinge (4pcs)	Damping hinge (4pcs)
M  ø7xø3.5x15mm	N 	O 
Flat head screw(48pcs+1)	Shelf Pin (4pcs+1)	Backplate clips(24pcs+1)
P  ø7xø3.5x15mm	Q  ø8x30mm	R  ø6x30mm
Flat head screw (24pcs+1)	Wood dowel(44pcs+1)	Wood dowel(4pcs+1)
S  4mm	T 	U  ø12x55mm
Allen key(1pc)	L-Bracket (2pcs)	Plastic stopper (2pcs+1)
V  ø10xø5x50mm	W  ø10xø5x20mm	X 
Round head screw (2pcs+1)	Round head screw (2pcs+1)	Power Adaptor(1pc)


STEP: 1





E

8PCS



STEP: 2

F	Q
	
2PCS	2PCS






STEP: 3

A	C	F	Q
4PCS	4PCS	2PCS	6PCS


S
1PC




STEP: 4

A	C	F	Q
2PCS	2PCS	1PC	4PCS

S
1PC




STEP: 5



STEP: 6


A	C	F	Q
4PCS	4PCS	3PCS	10PCS

S
1PC





STEP: 7

A	C	S
		
2PCS	2PCS	1PC




STEP: 8


O	P
	
24PCS	24PCS



STEP: 9


L	K	M
4PCS	4PCS	16PCS






STEP: 10


I	J	M
4PCS	8PCS	32PCS




Use the screws to adjust up or down




Use the screws to permanent




Use the screws to adjust left or right




Use the screws to adjust in or out





STEP: 11






STEP: 12








STEP: 13


F	Q
2PCS	2PCS




STEP: 14


B	D	F	Q
1PC	1PC	6PCS	8PCS

S
1PC







STEP: 15



B	D	F
		
1PC	1PC	6PCS


S	Q
	
1PC	8PCS

STEP: 16



F	Q
	
3PCS	2PCS


STEP: 17

G	R
	
8PCS	4PCS


STEP: 18


H

2PCS





STEP: 19






STEP: 20






STEP: 21

A	C	S
		
4PCS	2PCS	1PC




STEP: 22



STEP: 23


N
4PCS



STEP: 24


U

2PCS



STEP: 25

T	V	W
2PCS	2PCS	2PCS



STEP: 26

